


2026 ELIMINATOR® ABS PARTS DIAGRAM

Transmission



2026 ELIMINATOR® ABS PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT,13T (Ref # 13127)	13127-0727	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-0734	1
SPROCKET-OUTPUT,14T (Ref # 13144)	13144-0586	1
GEAR,INPUT 2ND,18T (Ref # 13262)	13262-1288	1
GEAR,INPUT 3RD&4TH,21T,24T (Ref # 13262A)	13262-1591	1
GEAR,INPUT 5TH,26T (Ref # 13262B)	13262-1592	1
GEAR,INPUT 6TH,27T (Ref # 13262C)	13262-1593	1
GEAR,OUTPUT LOW,41T (Ref # 13262D)	13262-1594	1
GEAR,OUTPUT 2ND,37T (Ref # 13262E)	13262-1595	1
GEAR,OUTPUT 3RD,34T (Ref # 13262F)	13262-1596	1
GEAR,OUTPUT 4TH,32T (Ref # 13262G)	13262-1597	1
GEAR,OUTPUT 5TH,30T (Ref # 13262H)	13262-1598	1
GEAR,OUTPUT 6TH,28T (Ref # 13262I)	13262-1599	1
WASHER,25.3X33X1 (Ref # 92022)	92022-1109	1
WASHER,20.5X30X1,STEEL (Ref # 92022A)	92022-112	1
BUSHING,OUTPUT 3RD&4TH GEAR (Ref # 92028)	92028-1858	1
RING-SNAP,20MM (Ref # 92033)	92033-015	2
RING-SNAP,24MM (Ref # 92033A)	92033-026	6
BEARING-BALL,6TM-6205NX3 (Ref # 92045)	92045-0735	1
BEARING-BALL,28X58X16 (Ref # 92045A)	92045-0841	1
BEARING-NEEDLE,KMJ20X26X13.8X1 (Ref # 92046)	92046-1185	2
RACE (Ref # 92048)	92048-0047	2
BUSHING,26X28X16.6 (Ref # 92139)	92139-0781	1
BUSHING,25X28X10.4 (Ref # 92139A)	92139-0793	2
COLLAR (Ref # 92152)	92152-2369	1
WASHER (Ref # 92200)	92200-1389	4
WASHER (Ref # 92200A)	92200-1932	1
WASHER,20.5X31X1.5 (Ref # 92200B)	92200-2523	2
WASHER,25.3X30X1 (Ref # 92200C)	92200-2524	2

2026 ELIMINATOR® ABS PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
NUT,20MM (Ref # 92210)	92210-0850	1
BALL-STEEL,5/32 (Ref # 600)	600A0500	3