


2026 Eliminator SE ABS PARTS DIAGRAM

Air Cleaner

E1130



2026 Eliminator SE ABS PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-1833	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-0767	1
VALVE,AIR CUT (Ref # 16126)	16126-0744	1
SEAL,CASE (Ref # 92093)	92093-0706	1
SEAL,ELEMENT (Ref # 92093A)	92093-0707	1
COLLAR,6.5X10.5X13.1 (Ref # 92152)	92152-0547	1
DAMPER (Ref # 92160)	92160-1162	1
DAMPER (Ref # 92161)	92161-1933	1
CLAMP (Ref # 92170)	92170-1017	3
CLAMP,18.8MM (Ref # 92171)	92171-2056	1
SCREW,5X25 (Ref # 92172)	92172-0891	9
CLAMP,20MM (Ref # 92173)	92173-0190	2
CLAMP,14MM (Ref # 92173A)	92173-0192	2
CLAMP (Ref # 92173B)	92173-1714	1
CLAMP (Ref # 92173C)	92173-2714	2
TUBE,DRAIN CLEAN (Ref # 92192)	92192-1744	1
TUBE,BREATHER (Ref # 92192A)	92192-1810	1
TUBE,AIR CUT VALVE-AIR CLEANER (Ref # 92192B)	92192-1811	1
TUBE,AIR CUT VALVE-HEAD CAP (Ref # 92192C)	92192-1812	1
TUBE,ISC-AIR CLEANER (Ref # 92192D)	92192-1813	1
WASHER,6.5X22X1.6 (Ref # 92200)	92200-1087	1
BOLT-FLANGED,6X25 (Ref # 130)	130BB0625	1