


# 1987 Tecate 4

## PARTS DIAGRAM

### Clutch

E1350-0146



# 1987 Tecate 4

## PARTS LIST

### Clutch

ITEM NAME	PART NUMBER	QUANTITY
CLUTCH-ASSY (Ref # 13081)	13081-1249	1
HUB-CLUTCH (Ref # 13087)	13087-1085	1
PLATE-FRICTION (Ref # 13088)	13088-1069	8
PLATE-CLUTCH (Ref # 13089)	13089-1074	7
HOUSING-COMP-CLUTCH (Ref # 13095)	13095-1160	1
RELEASE-COMP-CLUTCH (Ref # 13102)	13102-1088	1
PLATE-CLUTCH OPERATING (Ref # 13187)	13187-1060	1
ROD,CLUTCH (Ref # 46102)	46102-1146	1
BOLT,CLUTCH (Ref # 92002)	92002-1949	6
NUT,20MM (Ref # 92015)	92016-028	1
WASHER,10.2X18X1.0,SK5 (Ref # 92022)	92022-1415	AR
WASHER (Ref # 92022A)	92022-1835	1
WASHER,22.3X38X2.0 (Ref # 92022B)	92022-1836	2
BUSHING,22X28X27.5 (Ref # 92028)	92028-1385	1
RING-SNAP (Ref # 92033)	92036-023	1
BEARING-NEEDLE,28R3226 (Ref # 92046)	92046-1149	1
SPRING,CLUTCH (Ref # 92081)	92081-1151	6
BEARING-BALL,#6001C3 (Ref # 601)	601B6001	1