


1988 Tecate 4 PARTS DIAGRAM

Transmission

E1361-0189



1988 Tecate 4 PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT,14T (Ref # 13127A)	13127-1165	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1145	1
GEAR,INPUT 2ND,16T (Ref # 13129)	13129-1847	1
GEAR,INPUT 3RD&4TH,18&20T (Ref # 13129A)	13129-1848	1
GEAR,INPUT 5TH,24T (Ref # 13129B)	13129-1849	1
GEAR,INPUT TOP,25T (Ref # 13129C)	13129-1850	1
GEAR,OUTPUT LOW,33T (Ref # 13129D)	13129-1851	1
GEAR,OUTPUT 2ND,28T (Ref # 13129E)	13129-1852	1
GEAR,OUTPUT 3RD,25T (Ref # 13129F)	13129-1853	1
GEAR,OUTPUT 4TH,23T (Ref # 13129G)	13129-1854	1
GEAR,OUTPUT 5TH,24T (Ref # 13129H)	13129-1855	1
GEAR,OUTPUT TOP,22T (Ref # 13129I)	13129-1856	1
SPROCKET-OUTPUT,14T (Ref # 13144)	13144-1005	1
SPROCKET-OUTPUT,13T (Ref # 13144A)	13144-1027	1
WASHER,17.3X22X0.5 (Ref # 92022)	92022-1799	1
RING-SNAP,25MM (Ref # 92033)	92033-1089	1
RING-SNAP,20MM (Ref # 92033A)	92033-1231	1
RING-O (Ref # 92055)	92055-035	1
COLLAR,SPROCKET (Ref # 92143)	92143-1085	1