


1988 Tecate 4 PARTS DIAGRAM

Swingarm

F2141-0056



1988 Tecate 4 PARTS LIST

Swingarm

ITEM NAME	PART NUMBER	QUANTITY
CAP,SWING ARM (Ref # 11012)	11012-1259	1
BRACKET (Ref # 11045)	11045-1447	1
GUIDE-CHAIN,FR,LWR (Ref # 12053)	12053-1208	1
GUIDE-CHAIN,FR,UPP (Ref # 12053A)	12053-1213	1
GUIDE-CHAIN (Ref # 12053B)	12053-1218	1
GUIDE-CHAIN,LH (Ref # 12053C)	12053-1230	1
GUIDE-CHAIN,RH (Ref # 12053D)	12053-1231	1
ARM-COMP-SWING (Ref # 33001A)	33001-1310	1
SHAFT-SWING ARM (Ref # 33032A)	33032-1140	1
SLEEVE,SWING ARM (Ref # 42036)	42036-1064	1
ROD,TORQUE (Ref # 46102)	46102-1179	1
GUARD (Ref # 55020)	55020-1294	1
BOLT,10X28 (Ref # 92002)	92002-1733	1
BOLT,BRAKE ROD,10X30 (Ref # 92002A)	92002-1915	1
NUT,FLANGED,14MM (Ref # 92015)	92015-1032	1
NUT,FLANGED,6MM (Ref # 92015A)	92015-1193	1
NUT,LOCK,10MM (Ref # 92015B)	92015-1597	1
NUT,LOCK,12MM (Ref # 92015C)	92015-1617	1
BEARING-NEEDLE,TA2030Z (Ref # 92046)	92046-1128	1
COLLAR,L=26 (Ref # 92143)	92143-1155	1
BOLT-FLANGED,8X50 (Ref # 130)	130G0850	1
BOLT-FLANGED (Ref # 130B)	130P1260	1
BOLT-FLANGED-SMALL (Ref # 132)	132G0612	1
BOLT-FLANGED-SMALL (Ref # 132A)	132G0645	1
BOLT-UPSET-WS-SMALL (Ref # 183B)	183G0822	1
SCREW-CSK-CROS,6X10 (Ref # 221)	221B0610	1
WASHER-PLAIN-SMALL,12MM (Ref # 410)	410B1200	1
WASHER-PLAIN,8MM (Ref # 411)	411B0800	1
WASHER-SPRING,8MM (Ref # 461)	461F0800	1

1988 Tecate 4 PARTS LIST

Swingarm

ITEM NAME	PART NUMBER	QUANTITY
PIN-SNAP,10MM (Ref # 554)	554A1000	1