


1988 Tecate 4 PARTS DIAGRAM

Front Hub

F2230-0156



1988 Tecate 4 PARTS LIST

Front Hub

ITEM NAME	PART NUMBER	QUANTITY
HUB,FR (Ref # 49030)	49030-1084	1
BOLT,10X30 (Ref # 92002)	92002-1388	1
NUT,CASTLE,16MM (Ref # 92015)	42045-014	1
COLLAR,16.0X22X9.5 (Ref # 92027)	92027-1815	1
BEARING-BALL,60/22RD (Ref # 92045A)	92045-1218	1
SEAL-OIL (Ref # 92049)	92049-1197	1
SEAL-OIL,SDD4 28 44 8 (Ref # 92049A)	92049-1260	1
RING-O,21.5MM (Ref # 92055)	92055-1293	1
COLLAR,L=25 (Ref # 92143)	92143-1007	1
COLLAR,L=14.1 (Ref # 92143A)	92143-1008	1
PIN-COTTER,4.0X30 (Ref # 550)	550D4030	1
BEARING-BALL,#6203U (Ref # 601)	601A6203U	1