


1988 Tecate 4 PARTS DIAGRAM

Rear Hub

F2240-0205



1988 Tecate 4 PARTS LIST

Rear Hub

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,REAR CALIPER (Ref # 11045)	11045-1427	1
HOLDER,DISC PLATE (Ref # 13091)	13091-1472	1
FLANGE-COMP,SPROCKET (Ref # 39171)	39171-1052	1
HOUSING-BEARING (Ref # 41046)	41046-1080	1
AXLE,RR (Ref # 41068)	41068-1239	1
SPROCKET-HUB,38T (Ref # 42041)	42041-1262	1
SPROCKET-HUB,39T (Ref # 42041A)	42041-1263	1
SPROCKET-HUB,40T (Ref # 42041B)	42041-1264	1
SPROCKET-HUB,41T (Ref # 42041C)	42041-1265	1
SPROCKET-HUB,37T (Ref # 42041D)	42041-1289	1
RING,SNAP (Ref # 43058)	43058-1060	1
HUB,RR (Ref # 49030)	49030-1078	1
BOLT,10X30 (Ref # 92002)	92002-1388	1
BOLT,FLANGED,8X25 (Ref # 92002A)	92002-1903	1
NUT,CASTLE,18MM (Ref # 92015)	42045-018	1
NUT,LOCK,8MM (Ref # 92015A)	92015-1506	1
NUT,LOCK,37MM (Ref # 92015B)	92015-1545	1
NUT,AXLE,37MM (Ref # 92015C)	92015-1645	1
WASHER,94.5X108X1.0 (Ref # 92022)	92022-1858	1
WASHER,40.5X60X1.0 (Ref # 92022A)	92022-1859	1
WASHER,18.3X34X4.5 (Ref # 92022B)	92022-1953	1
RING-SNAP,95MM (Ref # 92033)	92033-1216	1
RING-SNAP,75MM (Ref # 92033A)	92033-1217	1
SEAL-OIL (Ref # 92049)	92049-1237	1
RING-O,76MM (Ref # 92055)	92055-1213	1
RING-O,38MM (Ref # 92055A)	92055-1317	1
CHAIN,DRIVE,EK520SR-02X96L (Ref # 92057A)	92057-1266	1
COLLAR,REAR AXLE,L=136 (Ref # 92143)	92143-1078	1
PIN-COTTER,3.2X35 (Ref # 550)	550D3235	1

1988 Tecate 4 PARTS LIST

Rear Hub

ITEM NAME	PART NUMBER	QUANTITY
BEARING-BALL,#6008UU (Ref # 601)	601A6008UU	1