


# 1988 Tecate 4

## PARTS DIAGRAM

### Shock Absorber(s)

F2280-0047



# 1988 Tecate 4

## PARTS LIST

### Shock Absorber(s)

ITEM NAME	PART NUMBER	QUANTITY
GASKET (Ref # 11009)	44045-057	4
CAP,REARSHOCK (Ref # 11012)	11012-1278	1
CAP,VALVE AIR (Ref # 11012A)	11012-1391	1
CAP,SHOCKABSORBER (Ref # 11012B)	11012-1636	2
GUIDE,SPRING (Ref # 13070)	13070-1150	1
GUIDE,SPRING (Ref # 13070A)	13070-1161	1
PIPE-COMP-SUSP (Ref # 39093)	39093-1117	1
CYLINDER-SHOCKABSORBER (Ref # 43089)	43089-1120	1
SHOCKABSORBER,FR (Ref # 45014B)	45014-1394	2
SHOCKABSORBER,RR (Ref # 45014C)	45014-1395	1
ROD,SHOCKABSORBER (Ref # 46102A)	46102-1240	1
TANK-OIL,SHOCKABSORBER (Ref # 52001)	52001-1073	1
JOINT-BALL (Ref # 59266)	59266-1053	3
BOLT,BANJO (Ref # 92001)	92001-1752	2
NUT,SPRING ADJUST LOCK (Ref # 92015)	92015-1551	1
NUT,SPRING GUIDE (Ref # 92015A)	92015-1552	1
COLLAR (Ref # 92027)	92027-1862	4
COLLAR,SHOCKABSORBER (Ref # 92027A)	92027-1976	2
BUSHING (Ref # 92028)	92028-1411	1
RING-SNAP (Ref # 92033)	92033-1090	3
RING-SNAP (Ref # 92033A)	92033-1206	1
RING-O,ROD (Ref # 92055)	92055-1181	1
BUSHING-RUBBER (Ref # 92092A)	92092-1058	1
BUSHING-RUBBER,SHOCKABSORBER (Ref # 92092B)	92092-1066	2
SEAL (Ref # 92093)	92093-1183	6
SPRING,SHOCKABSORBER,K=4.8 (Ref # 92144A)	92144-1263	1