

Fuel Injection



2026 JET SKI® ULTRA® 310LX PARTS LIST

Fuel Injection

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SWITCH (Ref # 11056)	11056-3855	1
BRACKET,REGULATOR&VDS (Ref # 11057)	11057-7354	1
BRACKET,RELAY (Ref # 11058)	11058-0929	1
HOLDER (Ref # 13280)	13280-0789	1
HOLDER,HARNESS (Ref # 13280A)	13280-3760	1
COVER,COUPLER (Ref # 14090)	14090-1611	2
REGULATOR-VOLTAGE (Ref # 21066)	21066-0755	1
CONTROL UNIT-ELECTRONIC,FI (Ref # 21175)	21175-2173	1
SENSOR,TEMP (Ref # 21176)	21176-0741	2
SENSOR,KNOCK (Ref # 21176A)	21176-0770	1
FUSE-ASSY,20A (Ref # 26004)	26004-0033	4
FUSE-ASSY,10A (Ref # 26004A)	26004-0034	2
FUSE-ASSY,15A (Ref # 26004B)	26004-0037	2
HARNESS (Ref # 26031)	26031-7092	1
RELAY-ASSY (Ref # 27002)	27002-3703	4
SWITCH (Ref # 27010)	27010-0710	1
SWITCH,VDS (Ref # 27010A)	27010-3785	1
BOLT,6X12 (Ref # 92002)	92002-3763	2
WASHER,6.5X20X1.5 (Ref # 92022)	92022-3710	2
CLAMP,L=100 (Ref # 92037)	92037-3736	2
RIVET (Ref # 92039)	92039-3714	2
BAND,L=188.85 (Ref # 92072)	92072-0105	1
BAND,OS170-FT7(BLACK) (Ref # 92072A)	92072-1414	AR
BAND,L=372.24 (Ref # 92072B)	92072-3883	13
BOLT,6X18 (Ref # 92150)	92150-3729	2
DAMPER,SWITCH (Ref # 92161)	92161-1625	1
CLAMP (Ref # 92173)	92173-0742	1
NUT,6MM (Ref # 92210)	92210-3768	2
BOLT,6X8 (Ref # 110)	110R0608	2

2026 JET SKI® ULTRA® 310LX PARTS LIST

Fuel Injection

ITEM NAME	PART NUMBER	QUANTITY
BOLT-WP,6X18 (Ref # 156)	156R0618	2
BOLT-WP,6X20 (Ref # 156A)	156R0620	6
SCREW-PAN-CROS,4X20 (Ref # 220)	220R0420	2