

Fuel Pump



2026 MULE PRO-DXT PARTS LIST

Fuel Pump

ITEM NAME	PART NUMBER	QUANTITY
SUPPORT (Ref # 13329)	13329-0001	1
COVER,GOVERNOR CASE (Ref # 14093)	14093-0448	1
SOLENOID,STOP (Ref # 21188)	21188-0013	1
SOLENOID,POWER CONTROL (Ref # 21188A)	21188-0022	1
PIPE,FEED (Ref # 32155)	32155-2047	1
PIPE,RETURN (Ref # 32155A)	32155-2048	1
PUMP-FUEL,INJECTION (Ref # 49040)	49040-0796	1
TUBE-ASSY (Ref # 51044)	51044-0785	1
CLAMP,HOSE CLIP (Ref # 92037)	92037-1181	9
KEY,WOODRUFF (Ref # 92038)	92038-0008	1
RING-O (Ref # 92055)	92055-0859	1
RING-O (Ref # 92055A)	92055-0860	1
RING-O (Ref # 92055B)	92055-0861	1
BOLT,FLANGED,8X63 (Ref # 92154)	92154-1940	2
BOLT,FLANGED,6X14 (Ref # 92154A)	92154-1997	2
BOLT,FLANGED,6X10 (Ref # 92154B)	92154-2068	3
BOLT,FLANGED,8X16 (Ref # 92154C)	92154-2071	2
CLAMP (Ref # 92170)	92170-1938	1
CLAMP (Ref # 92171)	92171-0515	5
CLAMP (Ref # 92173)	92173-1467	6
TUBE,7.5X13.5X390 (Ref # 92192)	92192-1476	2
TUBE,PUMP-FILTER (Ref # 92192A)	92192-1477	1
TUBE,FILER-ENGINE(FILTER SIDE) (Ref # 92192B)	92192-1478	1
TUBE,ENGINE-FILER(ENGINE SIDE) (Ref # 92192C)	92192-1479	1
TUBE,ENGINE-FILER(FILTER SIDE) (Ref # 92192D)	92192-1480	1
TUBE,FILTER-TANK (Ref # 92192E)	92192-1481	1
WASHER,SPRING (Ref # 92200)	92200-1810	1
NUT,12MM (Ref # 92210)	92210-1486	1
BOLT-FLANGED,6X12 (Ref # 130)	130BA0612	2