


# 1990 Ninja® ZX™-6 PARTS DIAGRAM

Transmission

E1361



# 1990 Ninja® ZX™-6 PARTS LIST

## Transmission

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP (Ref # 480)	480J2900	3
BALL-STEEL,5/32" (Ref # 600)	600A0500	3
SHAFT-TRANSMISSION INPUT,12T (Ref # 13127)	13127-1198	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1176	1
GEAR,INPUT 2ND,16T (Ref # 13129)	13129-1810	1
SPROCKET-OUTPUT,15T (Ref # 13144)	13144-1164	1
GEAR,OUTPUT LOW,38T (Ref # 13260)	13260-1125	1
GEAR,INPUT 3RD&4TH,35T&29T (Ref # 13260A)	13260-1142	1
GEAR,INPUT 5TH,23T (Ref # 13260B)	13260-1143	1
GEAR,INPUT TOP,24T (Ref # 13260C)	13260-1144	1
GEAR,OUTPUT 2ND,34T (Ref # 13260D)	13260-1145	1
GEAR,OUTPUT 3RD,35T (Ref # 13260E)	13260-1146	1
GEAR,OUTPUT 4TH,29T (Ref # 13260F)	13260-1147	1
GEAR,OUTPUT 5TH,28T (Ref # 13260G)	13260-1148	1
GEAR,OUTPUT TOP,26T (Ref # 13260H)	13260-1149	1
NUT,20MM (Ref # 92015)	92015-1254	1
WASHER,TOOTHED,25.5X42X1 (Ref # 92022)	92022-1076	1
WASHER,TOOTHED,28.3X33.5X1 (Ref # 92022A)	92022-1139	2
WASHER,TOOTHED,30.3X40X1.5 (Ref # 92022B)	92024-043	3
SPACER,22X35.5X2.1 (Ref # 92026)	92026-1224	2
BUSHING,INPUT TOP GEAR (Ref # 92028)	92028-1255	1
BUSHING,OUTPUT 3RD&4TH (Ref # 92028A)	92028-1363	1
BUSHING,INPUT 5TH GEAR (Ref # 92028B)	92028-1449	1
BUSHING,OUTPUT 2ND (Ref # 92028C)	92028-1450	1
RING-SNAP,20X25.5X1.2 (Ref # 92033)	92033-025	2
RING-SNAP,25.9MM (Ref # 92033A)	92033-1037	2
BEARING-BALL,83993SH2-CS (Ref # 92045)	92045-035	1
BEARING-BALL,6305N2SH2 (Ref # 92045A)	92045-1224	1
BEARING-NEEDLE,FWF-223014 (Ref # 92046)	92046-031	2

## 1990 Ninja® ZX™-6 PARTS LIST

Transmission

<b>ITEM NAME</b>	<b>PART NUMBER</b>	<b>QUANTITY</b>
RACE,INPUT SHAFT (Ref # 92048)	92048-1066	2
COLLAR,25X32X17.2 (Ref # 92143)	92143-1427	1