


# 1990 Ninja® ZX™-6 PARTS DIAGRAM

Step

F2160



# 1990 Ninja® ZX™-6 PARTS LIST

## Step

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP-TYPE-E,10MM (Ref # 482)	482L0100	2
CIRCLIP-TYPE-E,5MM (Ref # 482A)	482L5000	2
STEP,RR,LH (Ref # 34028)	34028-1191	1
STEP,RR,RH (Ref # 34028A)	34028-1192	1
STEP,FR,LH (Ref # 34028B)	34028-1328	1
STEP,FR,RH (Ref # 34028C)	34028-1329	1
BOLT,BANK SENSOR (Ref # 92002)	92002-1742	2
WASHER,STEP,RR (Ref # 92022)	92022-1507	2
COLLAR,STEP (Ref # 92027)	92027-1732	2
PIN,12X37 (Ref # 92043)	92043-1144	2
PIN,6X34 (Ref # 92043A)	92043-1271	2
SPRING,STEP RETURN (Ref # 92081)	92081-1587	1
SPRING,STEP,RR (Ref # 92081A)	92081-1612	2
SPRING,STEP,FR (Ref # 92081B)	92081-1733	1