

Ignition System

Let the Good Times Roll®

Diagram illustrating the assembly of a Kawasaki engine, showing various components and their reference numbers. The diagram includes a 'FRONT' arrow indicating orientation.

Key components and their reference numbers:

- Ref. Fuel Injection:** 21121, 92015, 411, 92152, (21150B), (21150A), (21150C), 92154, 26011, 21150, 21150A, 21150B, 21150C.
- Ref. Cylinder Head Cover:** 92072.
- Ref. Camshaft(s) / Tensioner:** 92072.
- Ref. Engine Cover(s):** 92009, 59026, 92009.
- Ref. Super Charger:** (26011).
- Ref. Cylinder Head:** 92043, 13061, 21007, 92150.
- Ref. Crankshaft:** 92153, 21007A.
- Ref. Super Charger:** 21176, 92055, 92002, 92072.

The diagram shows the engine block, cylinder head, camshaft, fuel injection system, and various covers and components, with their respective reference numbers and assembly points.

2026 JET SKI® ULTRA® 310LX

PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
BOSS,CAM SENSOR (Ref # 13061)	13061-1687	1
ROTOR,EX CAM (Ref # 21007)	21007-3742	1
ROTOR,PULSING (Ref # 21007A)	21007-3747	1
COIL-IGNITION (Ref # 21121)	21121-0744	2
CORD-ASSY,#1,L=340 (Ref # 21150)	21150-0006	1
CORD-ASSY,#2,L=450 (Ref # 21150A)	21150-0007	1
CORD-ASSY,#3,L=540 (Ref # 21150B)	21150-0008	1
CORD-ASSY,#4,L=600 (Ref # 21150C)	21150-0009	1
SENSOR,CAM ANGLE (Ref # 21176)	21176-1077	1
WIRE-LEAD (Ref # 26011)	26011-2417	1
COIL-PULSING (Ref # 59026)	59026-3702	1
BOLT,6X16 (Ref # 92002)	92002-3728	1
SCREW,5X12 (Ref # 92009)	92009-1296	4
NUT,LOCK,6MM (Ref # 92015)	92015-3766	2
PIN (Ref # 92043)	92043-1575	1
RING-O (Ref # 92055)	92055-1639	1
PLUG-SPARK,PMR9B(NGK) (Ref # 92070)	92070-3707	4
BAND,L=188.85 (Ref # 92072)	92072-0105	6
BOLT,6X18 (Ref # 92150)	92150-1645	1
COLLAR (Ref # 92152)	92152-3738	4
BOLT,FLANGED,8X23 (Ref # 92153)	92153-0549	1
BOLT,6X70 (Ref # 92154)	92154-4158	2
WASHER-PLAIN,6MM (Ref # 411)	411S0600	2