


2011 NINJA® ZX™-10R PARTS DIAGRAM

Transmission

E1361



2011 NINJA® ZX™-10R PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
BALL-STEEL,5/32 (Ref # 600)	600A0500	3
SHAFT-TRANSMISSION INPUT (Ref # 13127)	13127-0636	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-0670	1
SPROCKET-OUTPUT,17T,#525 (Ref # 13144)	13144-0004	1
GEAR,OUTPUT LOW,39T (Ref # 13262)	13262-0615	1
GEAR,OUTPUT 3RD,33T (Ref # 13262A)	13262-0803	1
GEAR,OUTPUT 4TH,33T (Ref # 13262B)	13262-0804	1
GEAR,OUTPUT 5TH,26T (Ref # 13262C)	13262-0805	1
GEAR,OUTPUT TOP,31T (Ref # 13262D)	13262-0806	1
GEAR,INPUT 2ND,19T (Ref # 13262E)	13262-0856	1
GEAR,INPUT TOP,23T (Ref # 13262F)	13262-0869	1
GEAR,OUTPUT 2ND,39T (Ref # 13262G)	13262-0880	1
GEAR,INPUT 5TH,18T (Ref # 13262H)	13262-0881	1
GEAR,INPUT 3RD&4TH,19T&21T (Ref # 13262I)	13262-0891	1
NUT,20MM (Ref # 92015)	92015-1963	1
RING-SNAP,25.9X30.6X1.2 (Ref # 92033)	92033-1037	5
RING-SNAP,T=1.5 (Ref # 92033A)	92033-1249	1
BEARING-BALL,830045-5SH2 (Ref # 92045)	92045-0047	1
BEARING-BALL,DG2152RDDSH2 (Ref # 92045A)	92045-0048	1
BEARING-BALL,63/22LU (Ref # 92045B)	92045-0156	1
BEARING-BALL,63/28 (Ref # 92045C)	92045-1189	1
RING-O,21.5X1.5 (Ref # 92055)	92055-1293	1
BUSHING,GEAR,6TH IN (Ref # 92139)	92139-0036	1
BUSHING,GEAR,LOW OUT (Ref # 92139A)	92139-0038	1
BUSHING,25.0X31.0X9.4 (Ref # 92139B)	92139-0309	2
BUSHING,28.1X31.0X13.5 (Ref # 92139C)	92139-0324	1
BUSHING,28.1X31.0X11.5 (Ref # 92139D)	92139-0734	1
COLLAR (Ref # 92152)	92152-0885	1
WASHER,28.3X34.0X1.6 (Ref # 92200)	92200-0050	5

2011 NINJA® ZX™-10R PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
WASHER,22.1X32.0X1.4 (Ref # 92200A)	92200-0138	2
WASHER (Ref # 92200B)	92200-1065	1
WASHER,25.8X40.5X1.5 (Ref # 92200C)	92200-1522	2
WASHER,25.2X37.0X1.0 (Ref # 92200D)	92200-1523	2