


# 2015 ZR800 (European)

## PARTS DIAGRAM

### Ignition Switch



# 2015 ZR800 (European)

## PARTS LIST

### Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,6X12 (Ref # 120)	120CB0612	2
BRACKET,CLASP (Ref # 11056)	11056-0238	1
BRACKET,SEAT LOCK (Ref # 11056A)	11056-2119	1
BRACKET (Ref # 11056B)	11056-2394	1
ROTOR,LOCK,TANK,CAP (Ref # 21007)	21007-5072	1
AMPLIFIER,IMMOBI (Ref # 21181)	21181-0056	1
SWITCH-ASSY-IGNITION,IMMOBI (Ref # 27005)	27005-0581	1
KEY-LOCK,BLANK,IMMOBI (Ref # 27008)	27008-0558	1
SWITCH,SIDE STAND (Ref # 27010)	27010-0722	1
SWITCH,REAR BRAKE (Ref # 27010A)	27010-0723	1
LOCK-ASSY,SEAT STRIKER (Ref # 27016)	27016-0008	1
LOCK-ASSY,SEAT (Ref # 27016A)	27016-5380	1
SWITCH-ASSY (Ref # 27045)	27045-5484	1
REFLECTOR-REFLEX (Ref # 28012)	28012-1077	1
COLLAR,L=9.6 (Ref # 92027)	92027-1045	2
DAMPER (Ref # 92075)	92075-1564	4
SPRING,REAR BRAKE (Ref # 92145)	92145-0946	1
BOLT,TORX,6X22 (Ref # 92151)	92151-1946	3
BOLT,SOCKET,6X22 (Ref # 92154)	92154-0031	1
BOLT,FLANGED,6X25 (Ref # 92154A)	92154-1212	2
WASHER,6X20X1.6 (Ref # 92200)	92200-0780	2
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	1