


Mule 1000 PARTS DIAGRAM

Rear Hubs/Brakes

F2240-0215



Mule 1000 PARTS LIST

Rear Hubs/Brakes

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET-WS,10X16 (Ref # 190)	190H1016	8
WASHER-SPRING,18MM (Ref # 461)	461F1800	2
CAP,WHEEL (Ref # 11012)	11012-1519	2
LEVER-COMP,REAR BRAKE PANEL,LH (Ref # 13236)	13236-1180	1
LEVER-COMP,REAR BRAKE PANEL,RH (Ref # 13236A)	13236-1181	1
HOOK,REAR BRAKE LEVER (Ref # 27012)	27012-1396	2
STOPPER,REAR BRAKE LEVER (Ref # 32085)	32085-1298	2
PANEL-ASSY-BRAKE,RR,LH (Ref # 41035)	41035-1268	1
PANEL-ASSY-BRAKE,RR,RH (Ref # 41035A)	41035-1269	1
DRUM,REAR BRAKE (Ref # 41038)	41038-1206	2
SHOE-BRAKE (Ref # 41048)	41048-1078	2
SHOE-BRAKE (Ref # 41048A)	41048-1079	2
CYLINDER,REAR WHEEL (Ref # 43092)	43092-1053	2
BOLT,10X30 (Ref # 92002)	92002-1388	8
NUT,CASTLE,18MM (Ref # 92015)	92015-1441	2
NUT,6MM (Ref # 92015A)	92015-1729	4
WASHER,18.3X36X4.5 (Ref # 92022)	92022-1920	2
WASHER,SPRING,6MM (Ref # 92022A)	92022-1951	4
COTTER,4.0X35 (Ref # 92041)	92041-1053	2
PIN,TENSION (Ref # 92043)	92043-1398	4
PLUG (Ref # 92066)	92066-1309	2
SPRING,SHOE CLAMP (Ref # 92081)	92081-1904	4
SEAL,REAR BRAKE LEVER (Ref # 92093)	92093-1259	2
SPRING,BRAKE (Ref # 92144)	92144-1299	1
SPRING,BRAKE (Ref # 92144A)	92144-1300	1
SPRING,BRAKE (Ref # 92144B)	92144-1301	2
SPRING,ROD,LH (Ref # 92144C)	92144-1302	1
SPRING,ROD,RH (Ref # 92144D)	92144-1303	1