


Mule 500 PARTS DIAGRAM

Front Hubs/Brakes



Mule 500 PARTS LIST

Front Hubs/Brakes

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET-WS-SMALL (Ref # 183)	183H0814	1
CAP,WHEEL (Ref # 11012)	11012-1519	1
LEVER,STOPPER,LH (Ref # 13168)	13168-1477	1
LEVER,STOPPER,RH (Ref # 13168A)	13168-1478	1
LEVER,LH (Ref # 13168B)	13168-1479	1
LEVER,RH (Ref # 13168C)	13168-1480	1
KNUCKLE,LH (Ref # 39186)	39186-1094	1
KNUCKLE,RH (Ref # 39186A)	39186-1095	1
PANEL-ASSY-BRAKE,FR,LH (Ref # 41035)	41035-1280	1
PANEL-ASSY-BRAKE,FR,RH (Ref # 41035A)	41035-1281	1
DRUM,FRONT BRAKE (Ref # 41038)	41038-1238	1
SHOE-ASSY-BRAKE,FR (Ref # 41047)	41047-1051	1
NUT,CASTLE,18MM (Ref # 42045)	42045-018	1
CAP-BREATHER (Ref # 43057)	43057-1053	1
CYLINDER (Ref # 43092)	43092-1057	1
BOLT,10X30 (Ref # 92002)	92002-1388	1
RING-SNAP (Ref # 92033)	92033-1279	1
COTTER,4.0X35 (Ref # 92041)	92041-1053	1
PIN,SHOE HOLD (Ref # 92043)	92043-1460	1
BEARING-BALL,60/222RS (Ref # 92045)	92045-1170	1
SEAL-OIL (Ref # 92049)	92049-1284	1
PLUG (Ref # 92066)	92066-1365	1
SEAL (Ref # 92093)	92093-1332	1
COLLAR,22.2X28.6X9 (Ref # 92143)	92143-1454	1
COLLAR,22.2X28.6X25 (Ref # 92143A)	92143-1455	1
SPRING (Ref # 92144)	92144-1604	1
SPRING,LH (Ref # 92144C)	92144-1607	1
SPRING,RH (Ref # 92144D)	92144-1608	1
SPRING,SHOE HOLD (Ref # 92144E)	92144-1609	1

Mule 500 PARTS LIST

Front Hubs/Brakes

ITEM NAME	PART NUMBER	QUANTITY
SPRING,SHOE HOLD (Ref # 92144F)	92144-1610	1
SPRING,SHOE HOLD (Ref # 92144G)	92144-1611	1
SPRING,RETURN,UPP (Ref # 92144H)	92144-1612	1
SPRING,RETURN,LWR (Ref # 92144I)	92144-1613	1
BOLT,FLANGED,6X10 (Ref # 92150)	92150-1664	1