


# Mule 2500 PARTS DIAGRAM

Driven Converter

E1392



## Mule 2500 PARTS LIST

### Driven Converter

| ITEM NAME                             | PART NUMBER | QUANTITY |
|---------------------------------------|-------------|----------|
| BALANCER,T=0.8 (Ref # 13041)          | 13041-1084  | AR       |
| BALANCER,T=1.0 (Ref # 13041A)         | 13041-1085  | AR       |
| COUPLING-ASSY (Ref # 42033)           | 42033-1124  | 1        |
| SHOE (Ref # 49048)                    | 49048-1054  | 3        |
| RAMP (Ref # 49092)                    | 49092-1051  | 1        |
| CONVERTER-ASSY-DRIVEN (Ref # 49094)   | 49094-1051  | 1        |
| SHEAVE-COMP,FIXED (Ref # 59302)       | 59302-1053  | 1        |
| SHEAVE-COMP,MOVABLE (Ref # 59302A)    | 59302-1054  | 1        |
| WASHER,12.5X32X3.2 (Ref # 92022)      | 92022-1982  | 1        |
| BUSHING,50X55X20 (Ref # 92028)        | 92028-1512  | 1        |
| BUSHING,32X36X20 (Ref # 92028A)       | 92028-1513  | 1        |
| BUSHING,25X28X30 (Ref # 92028B)       | 92028-1514  | 1        |
| RING-SNAP (Ref # 92033)               | 92033-1241  | 1        |
| SPRING,DRIVEN CONVERTER (Ref # 92144) | 92144-1197  | 1        |
| BOLT,12X35 (Ref # 92150)              | 92150-1009  | 1        |
| BOLT,6X20 (Ref # 92150A)              | 92150-1014  | 6        |