


# Mule 520 PARTS DIAGRAM

Crankcase

E1411



## Mule 520 PARTS LIST

### Crankcase

| ITEM NAME                            | PART NUMBER | QUANTITY |
|--------------------------------------|-------------|----------|
| GASKET,CRANKCASE COVER (Ref # 11060) | 11060-2122  | 1        |
| BAFFLE (Ref # 18020)                 | 18020-2072  | 1        |
| COVER-CRANKCASE (Ref # 49015)        | 49015-6192  | 1        |
| CRANKCASE-COMP (Ref # 49120)         | 49120-6062  | 1        |
| STUD,6X14 (Ref # 92004)              | 92004-2083  | 4        |
| SCREW (Ref # 92009)                  | 92009-2308  | 1        |
| PIN,DOWEL,10X14 (Ref # 92043)        | 92043-1037  | 2        |
| PIN,6.2X8X14 (Ref # 92043A)          | 92043-1263  | 2        |
| BEARING-BALL,6306JRCM (Ref # 92045)  | 92045-2168  | 1        |
| SEAL-OIL,VC-6X10X2.5 (Ref # 92049)   | 92049-2097  | 1        |
| SEAL-OIL (Ref # 92049A)              | 92049-2199  | 1        |
| SEAL-OIL (Ref # 92049B)              | 92049-2220  | 1        |
| BOLT,8X45 (Ref # 92150)              | 92150-2252  | 8        |