


2008 Mule 3010 Trans4x4 Diesel PARTS DIAGRAM

Fuel Pump

E1520



2008 Mule 3010 Trans4x4 Diesel PARTS LIST

Fuel Pump

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,8X25 (Ref # 130)	130J0825	2
GASKET,AIR VENT (Ref # 11060)	11060-1978	1
GASKET (Ref # 11060A)	11060-1979	1
CAP-ASSY,DRAIN (Ref # 14075)	14075-1109	1
BODY,FUEL FILTER (Ref # 16160)	16160-1328	1
PIPE,FUEL (Ref # 32154)	32154-7607	2
FILTER-FUEL (Ref # 49019)	49019-1094	1
ELEMENT-FUEL FILTER (Ref # 51056)	51056-1051	1
CLAMP,HOSE CLIP (Ref # 92037)	92037-1181	7
CLAMP,TUBE (Ref # 92037A)	92037-1505	1
PLUG,AIR VENT (Ref # 92066)	92066-1538	1
BAND,L=188 (Ref # 92072)	92072-1239	3
BAND,L=368.3 (Ref # 92072A)	92072-3872	2
CLAMP (Ref # 92170)	92170-1938	2
TUBE,INJECTION INLET (Ref # 92191)	92191-1437	1
TUBE,INJECTION OUTLET (Ref # 92191A)	92191-1438	1
TUBE,DRAIN,8X11X100 (Ref # 92191B)	92191-1565	1
TUBE,FUEL TANK-PIPE (Ref # 92192)	92192-7508	2
TUBE,PIPE-FUEL FILTER (Ref # 92192A)	92192-7509	1