


# 2008 Mule 3010 Trans4x4 Diesel PARTS DIAGRAM

Generator



# 2008 Mule 3010 Trans4x4 Diesel PARTS LIST

## Generator

| ITEM NAME                              | PART NUMBER | QUANTITY |
|----------------------------------------|-------------|----------|
| BRACKET,LWR (Ref # 11051)              | 11051-1568  | 1        |
| BRACKET,UPP (Ref # 11051A)             | 11051-1569  | 1        |
| BRACKET (Ref # 11054)                  | 11054-7512  | 1        |
| CAP,GLOW (Ref # 11065)                 | 11065-1150  | 3        |
| CONNECTOR (Ref # 13159)                | 13159-1066  | 1        |
| HOUSING,ALTERNATOR (Ref # 13227)       | 13227-1139  | 1        |
| HOLDER,RECTIFIER (Ref # 13280)         | 13280-1173  | 1        |
| HOLDER,ALTERNATOR BRUSH (Ref # 13280A) | 13280-1174  | 1        |
| HOLDER,BEARING (Ref # 13280B)          | 13280-1175  | 1        |
| PLATE-POSITION (Ref # 14014)           | 14014-1149  | 1        |
| COVER,REAR END (Ref # 14091)           | 14091-1207  | 1        |
| INSULATOR (Ref # 16073)                | 16073-1122  | 1        |
| COVER-ASSY,RECTIFIER (Ref # 16146)     | 16146-1214  | 1        |
| GENERATOR (Ref # 21001)                | 21001-1176  | 1        |
| ROTOR,ALTERNATOR (Ref # 21007)         | 21007-1368  | 1        |
| BRUSH (Ref # 21039)                    | 21039-1068  | 2        |
| REGULATOR-VOLTAGE (Ref # 21066)        | 21066-1122  | 1        |
| RELAY-ASSY (Ref # 27002)               | 27002-1086  | 1        |
| RELAY,HEATING TIMER (Ref # 27034)      | 27034-1065  | 1        |
| RELAY,GLOW (Ref # 27034A)              | 27034-1066  | 1        |
| PLUG-GLOW (Ref # 49036)                | 49036-1051  | 3        |
| PULLEY,ALTERNATOR (Ref # 59091)        | 59091-1106  | 1        |
| STUD,ALTERNATOR HOUSING (Ref # 92004)  | 92004-1273  | 2        |
| SCREW (Ref # 92009)                    | 92009-1921  | 2        |
| SCREW (Ref # 92009A)                   | 92009-1922  | 1        |
| SCREW (Ref # 92009B)                   | 92009-1923  | 6        |
| SCREW,POSITION PLATE (Ref # 92009C)    | 92009-1924  | 4        |
| BEARING-BALL,373 (Ref # 92045)         | 92045-1398  | 1        |
| BEARING-BALL,6002DG6 (Ref # 92045A)    | 92045-1399  | 1        |

## 2008 Mule 3010 Trans4x4 Diesel PARTS LIST

### Generator

| ITEM NAME                             | PART NUMBER | QUANTITY |
|---------------------------------------|-------------|----------|
| SPRING,ALTERNATOR BRUSH (Ref # 92145) | 92145-1312  | 2        |
| BOLT,10X40 (Ref # 92151)              | 92151-1691  | 1        |
| BOLT,8X25 (Ref # 92151A)              | 92151-1692  | 2        |
| BOLT,8X20 (Ref # 92151B)              | 92151-1693  | 1        |
| BOLT,8X45 (Ref # 92151C)              | 92151-1694  | 1        |
| BOLT (Ref # 92151D)                   | 92151-1715  | 3        |
| BOLT (Ref # 92151E)                   | 92151-1716  | 2        |
| COLLAR (Ref # 92152)                  | 92152-1230  | 1        |
| NUT,6MM (Ref # 92210)                 | 92210-1210  | 1        |
| NUT,GLOW PLUG,4MM (Ref # 92210A)      | 92210-1218  | 3        |
| NUT,PULLEY (Ref # 92210B)             | 92210-1232  | 1        |
| BOLT-FLANGED-SMALL,5X12 (Ref # 132)   | 132J0512    | 1        |
| BOLT-FLANGED-SMALL,6X12 (Ref # 132A)  | 132J0612    | 2        |
| NUT (Ref # 92210C)                    | 92210-1233  | 2        |
| NUT (Ref # 92210D)                    | 92210-1234  | 1        |