


2008 Prairie® 360 4X4

PARTS DIAGRAM

Valve(s)

E1210



2008 Prairie® 360 4X4

PARTS LIST

Valve(s)

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL,6X30 (Ref # 132)	132BD0630	4
O RING,10MM (Ref # 670)	670D1510	2
GASKET,6.2X12X0.3 (Ref # 11060)	11060-1994	4
VALVE-INTAKE (Ref # 12004)	12004-1155	1
VALVE-EXHAUST (Ref # 12005)	12005-1326	1
RETAINER-VALVE SPRING (Ref # 12009)	12009-005	2
COLLET,RETAINER (Ref # 12011)	12011-004	4
ARM-ROCKER (Ref # 12016)	12016-0024	2
SHAFT-ROCKER (Ref # 12020)	12020-1085	2
SEAT-SPRING,VALVE (Ref # 16007)	16007-1024	2
SPRING-ENGINE VALVE,INNER (Ref # 49078)	49078-1209	2
SPRING-ENGINE VALVE,OUTER (Ref # 49078A)	49078-1210	2
SCREW,VALVE ADJUST (Ref # 92009)	92009-1109	2
NUT,VALVE ADJUST LOCK (Ref # 92015)	92015-1137	2
SEAL-OIL,RV37129.5 (Ref # 92049)	92049-016	2
SPRING,ROCKER SHAFT (Ref # 92145)	92145-1532	2
WASHER,13.4X25X1.0 (Ref # 92200)	92200-0045	2