


2012 EDGE VR

PARTS DIAGRAM

Ignition Switch

Kawasaki

Let the Good Times Roll®



2012 EDGE VR

PARTS LIST

Ignition Switch

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
CAP,IGNITION SWITCH (Ref # 11065)	11065-0361	1
SWITCH,REAR BRAKE (Ref # 27010)	27010-0048	1
SWITCH,DIMMER (Ref # 27010A)	27010-0052	1
SWITCH,HORN (Ref # 27010B)	27010-0053	1
SWITCH,STARTER (Ref # 27010C)	27010-0055	1
SWITCH,LIGHTING (Ref # 27010D)	27010-0056	1
SWITCH,TURN SIGNAL (Ref # 27010E)	27010-0096	1
LOCK-ASSY,SEAT (Ref # 27016)	27016-0072	1
LOCK-ASSY,SEAT (Ref # 27016A)	27016-5366	1
SWITCH-ASSY,IGNITION (Ref # 27045)	27045-0552	1
SWITCH-ASSY (Ref # 27045A)	27045-9504	1
SNAP,SEAT LOCK (Ref # 39124)	39124-0002	1
PLATE-THRUST (Ref # 49074)	49074-0001	1
NUT,FLANGED,6MM (Ref # 92015)	92015-1367	4
SPRING,REAR BRAKE SWITCH (Ref # 92145)	92145-0250	1