

Chassis Electrical Equipment

Let the Good Times Roll®

Diagram illustrating the front of the vehicle, showing the location of the Fuse Box and various electrical components.

Fuse Box

The Fuse Box is located in the front left corner of the vehicle. It contains several fuses, including:

- 26006A
- 26006
- 26006A
- 26006
- 26006A
- 26006
- 26006A

Other components shown include:

- 26031
- 92072A
- 26011D
- 56030
- 56030A
- 26011A
- 130



2007 ER-6n (Australian)

PARTS LIST

Chassis Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X10 (Ref # 130)	130BA0610	2
BOLT-FLANGED-SMALL,8X12 (Ref # 132)	132BB0812	1
FUSE,15A (Ref # 26006)	26006-0001	3
FUSE,10A (Ref # 26006A)	26006-1078	8
WIRE-LEAD,BATTERY(+) (Ref # 26011)	26011-0073	1
WIRE-LEAD (Ref # 26011A)	26011-0082	1
WIRE-LEAD,BATTERY(-) (Ref # 26011C)	26011-0099	1
WIRE-LEAD,SENSOR CONNECTOR (Ref # 26011D)	26011-0101	1
BATTERY,YTX12-BS,12V 10AH (Ref # 26012)	26012-0094	1
HARNESS,MAIN (Ref # 26031)	26031-0400	1
RELAY-ASSY (Ref # 27002)	27002-0007	1
RELAY-ASSY,TURN SIGNAL (Ref # 27002A)	27002-0010	1
HORN (Ref # 27003)	27003-0051	1
LABEL,FUSE BOX (Ref # 56030)	56030-0046	1
LABEL,FUSE BOX (Ref # 56030A)	56030-0098	1
CLAMP,SPEED,L=58 (Ref # 92037)	92037-1163	1
CLAMP,HARNESS (Ref # 92037A)	92037-1316	3
CLAMP,HOSE (Ref # 92037B)	92037-1827	2
BAND,L=365 (Ref # 92072)	92072-1197	2
BAND (Ref # 92072A)	92072-1414	13
BOLT,SOCKET,6X14 (Ref # 92153)	92153-1446	1
DAMPER,SIGNAL RELAY (Ref # 92161)	92161-0283	1
CLAMP,DIA=20 (Ref # 92171)	92171-0069	3
CLAMP (Ref # 92171A)	92171-0640	2
CLAMP,HARNESS (Ref # 92171B)	92171-0657	1
CLAMP,DIA=13 (Ref # 92171C)	92171-1415	1
CLAMP,DIA=15 (Ref # 92171D)	92171-1424	1
CLAMP,DIA=25 (Ref # 92171E)	92171-1559	1