


2006 Ninja[®] 250R

PARTS DIAGRAM

Front Wheel



2006 Ninja® 250R

PARTS LIST

Front Wheel

ITEM NAME	PART NUMBER	QUANTITY
WASHER-PLAIN-SMALL,14MM (Ref # 410)	410B1400	1
CIRCLIP-TYPE-C,35MM (Ref # 481)	481J3500	1
PIN-COTTER,3.0X25 (Ref # 550)	550D3025	1
BEARING-BALL,#6202UG (Ref # 601)	601B6202UG	2
GEAR-METER SCREW,23T (Ref # 41060)	41060-1107	1
RECEIVER-SPEEDOMETER (Ref # 41064)	41064-1006	1
AXLE,FR (Ref # 41068)	41068-0024	1
WHEEL-ASSY,FR,BLACK (Ref # 41073)	41073-1365-QT	1
CASE-ASSY-METER GEAR (Ref # 41078)	41078-1055	1
NUT,CASTLE,14MM (Ref # 92015)	92015-1765	1
COLLAR,L=36.5 (Ref # 92027)	92027-1979	1
COLLAR,15.2X22X60 (Ref # 92027A)	92027-1980	1
RING-SNAP,42MM (Ref # 92033)	92033-1041	1
SEAL-OIL,BJN30427-C3 (Ref # 92049)	92049-1057	1
SEAL-OIL,22X35X8 (Ref # 92049A)	92049-1348	1