

1982 KZ440-G1



PARTS DIAGRAM

FOOTRESTS

Kawasaki

Let the Good Times Roll®

F2160-0049



1982 KZ440-G1

PARTS LIST FOOTRESTS

ITEM NAME	PART NUMBER	QUANTITY
HOLDER-STEP,RR (Ref # 34003)	34003-1025	2
HOLDER-STEP,FR,LH (Ref # 34003A)	34003-1126	1
HOLDER-STEP,FR,RH (Ref # 34003B)	34003-1127	1
STEP,FOOTREST,REAR,LH (Ref # 34028)	34028-1009	1
STEP,FOOTREST,REAR,RH (Ref # 34028A)	34028-1010	1
STEP-ASSY,FR,RH (Ref # 34028B)	34028-1018	1
STEP-ASSY,FR,RH (Ref # 34028C)	34028-1018	1
WASHER,PLAIN (Ref # 92022)	92022-250	2
WASHER,PLAIN (Ref # 92022A)	92022-250	2
PIN (Ref # 92043)	92043-1464	2
PIN,FOOTREST BAR FIT (Ref # 92043A)	92043-115	2
BOLT-SMALL-FINE,10X45 (Ref # 113)	113G1045	2
NUT,10MM (Ref # 314)	314B1000	2
WASHER PLAIN 10MM (Ref # 410)	410B1000	2
WASHER SPRING 10MM (Ref # 461)	461F1000	2
PIN,COTTER,2.0X12 (Ref # 550)	550D2012	2
PIN,COTTER,2.5X15 (Ref # 550A)	550D2515	2