


1973 F9-A

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT ('72-'73 F9

Kawasaki

Let the Good Times Roll®



1973 F9-A

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT ('72-'73 F9

ITEM NAME	PART NUMBER	QUANTITY
WIRING HARNESS-MAIN (Ref # 1)	26001-069	
UNAVAILABLE IN PRICE BOOK (Ref # 1)	26001-078	
WIRING HARNWSS REAR (Ref # 2)	26002-027	
WIRING HARNESS-REAR (Ref # 2)	26002-029	
WIRE BATTERY GROUND (Ref # 3)	26010-017	
WIRE,LEAD (Ref # 3-1)	26011-093	
LEAD WIRE (Ref # 4)	26011-042	
FUES ASSY (Ref # 5)	26004-008	
FUSE 10A (Ref # 6)	26006-003	
SWITCH-BRAKE LAMP (Ref # 7)	27010-018	
SPRING BRAKE LAMP SW (Ref # 8)	27011-004	
YUA BAT 6N2-2A-3 (Ref # 9)	26012-021	
YUA BAT 6N4B-2A-3 (Ref # 9)	26012-035	
LAMP-FRONT TURN SIG (Ref # 10)	23040-032	
LAMP-REAR TURN SIGNA (Ref # 11)	23043-030	
WASHER PLAIN 10MM (Ref # 12)	410B1000	
WASHER SPRING 10MM (Ref # 13)	461F1000	
NUT 10MM (Ref # 14)	315B1000	
SCREW OVL CNTSNK 3X1 (Ref # 15)	222B0315A	
LENS TURN SIGNAL LAM (Ref # 16)	23048-011	
BULB,6V 8W (Ref # 17)	92069-042	
RELAY-TURN SIGNAL (Ref # 18)	27002-009	
SCREW PAN HEAD 6X16 (Ref # 19)	220B0616	
WASHER PLAIN 6MM (Ref # 20)	410B0600	
WASHER SPRING 6MM (Ref # 21)	461F0600	
BRACKET-TRN.SGNL.RLY (Ref # 22)	27023-001	
WIRING HARNESS-MAIN (Ref # 23)	26001-054	
WIRE-LEAD (Ref # 24)	26011-058	
BAND,SHORT (Ref # 25)	92072-030	

1973 F9-A

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT ('72-'73 F9

ITEM NAME	PART NUMBER	QUANTITY
BAND,MIDDLE (Ref # 26)	92072-031	
BAND,LONG (Ref # 27)	92072-032	
HORN (Ref # 28)	27003-062	
HORN (Ref # 28)	27003-062	
BOLT-UPSET,6X20 (Ref # 29)	112G0620	
WASHER PLAIN 6MM (Ref # 30)	411B0600	
WASHER SPRING 6MM (Ref # 31)	461F0600	
NUT 6MM (Ref # 32)	311B0600	
HORN (Ref # 33)	27003-057	
HORN (Ref # 33)	27003-057	