

PARTS DIAGRAM SWING ARM ('81 A7)

Let the Good Times Roll®



F2140-0006



1981 KX125

PARTS LIST

SWING ARM ('81 A7)

ITEM NAME	PART NUMBER	QUANTITY
CAP,SWING ARM (Ref # 11012)	11012-1099	4
GUIDE,CHAIN,REAR (Ref # 12053)	12053-1039	1
GUIDE,CHAIN,FRONT (Ref # 12053A)	12053-1046	1
ARM,SWING (Ref # 33001)	33001-1047	1
SHAFT-SWING ARM (Ref # 33032)	33032-1020	1
ADJUSTER,CHAIN (Ref # 33040)	33040-1012	2
SLEEVE,SWING ARM (Ref # 42036)	42036-1031	2
GUARD,CHAIN (Ref # 55020)	55020-1038	1
BOLT,CHAIN ADJUSTER (Ref # 92001)	92001-1027	2
NUT (Ref # 92015)	92019-008	2
NUT-LOCK,14MM (Ref # 92015A)	92019-011	1
WASHER 6.5X20X1.6T (Ref # 92022)	92022-125	3
SHIM,SWING ARM (Ref # 92025)	92025-1116	4
BRG,NEEDLE,HMK2030 (Ref # 92046)	92046-1031	2
BOLT-UPSET,6X20 (Ref # 110)	112G0620	1
BOLT-UPSET (Ref # 110A)	112G0660	2
NUT 8MM (Ref # 318)	318G0800	2