


1984 KDX250

PARTS DIAGRAM FRONT HUB/BRAKE

Kawasaki
Let the Good Times Roll®



1984 KDX250

PARTS LIST

FRONT HUB/BRAKE

ITEM NAME	PART NUMBER	QUANTITY
CASE-ASSY,DISTANCE SE (Ref # 11021)	11021-1064	1
DRUM-ASSY,FR (Ref # 41034)	41034-1067	1
PANEL-ASSY-BRAKE,FR (Ref # 41035A)	41035-1121	1
SHOE-BRAKE (Ref # 41048)	41048-1068	2
CAM-BRAKE,FR (Ref # 41050A)	41050-1033	1
LEVER,FRONT BRAKE CAM (Ref # 41053)	41053-1003	1
AXLE,FR (Ref # 41068)	41068-1073	1
INDICATOR,FRONT BRAKE (Ref # 41085)	41085-001	1
NUT,14MM (Ref # 92015)	92015-1407	1
COLLAR,L=54.5 (Ref # 92027)	92027-1458	1
SPRING-BRAKE SHOE (Ref # 92081)	42020-004	2
BOLT-UPSET (Ref # 110)	112G0622	1
WASHER PLAIN 6MM (Ref # 410)	410B0600	1
CIRCLIP,35MM (Ref # 481)	481J3500	1
"O" RING,15MM (Ref # 601)	670B2015	2
"O" RING,15MM (Ref # 670)	670B2015	1