

1983 KX250


PARTS DIAGRAM

FOOTRESTS ('83 KX250-C1)

Kawasaki
Let the Good Times Roll®



F2160-0076



1983 KX250

PARTS LIST

FOOTRESTS ('83 KX250-C1)

ITEM NAME	PART NUMBER	QUANTITY
STEP,LH (Ref # 34028)	34028-1050	1
STEP,RH (Ref # 34028A)	34028-1051	1
PIN (Ref # 92043)	92043-1107	2
SPRING,L.H STEP (Ref # 92081)	92081-1410	1
SPRING,R.H STEP (Ref # 92081A)	92081-1411	1
PIN,COTTER (Ref # 550)	550D2018	2