


1984 KX250

PARTS DIAGRAM

IGNITION ('84 KX250-C2)

Kawasaki
Let the Good Times Roll®

E1810-0078



1984 KX250

PARTS LIST

IGNITION ('84 KX250-G2)



ITEM NAME	PART NUMBER	QUANTITY
STATOR (Ref # 21003)	21003-1101	1
ROTOR (Ref # 21007)	21007-1102	1
IGNITER (Ref # 21119)	21119-1103	1
WASHER,PLAIN,8MM (Ref # 92022)	92022-276	1
WOODRUFF KEY (Ref # 92038)	92038-001	1
BOLT-FLANGED,6X16 (Ref # 130)	130G0616	1
SCREW-PAN-WP-CROS (Ref # 235)	235B0616	2