



1984 KX250

PARTS DIAGRAM

FOOTRESTS ('84 KX250-C2)

Kawasaki
Let the Good Times Roll®

F2160-0107



1984 KX250

PARTS LIST

FOOTRESTS ('84 KX250-C2)

ITEM NAME	PART NUMBER	QUANTITY
STEP,LH (Ref # 34028)	34028-1104	1
STEP,RH (Ref # 34028A)	34028-1105	1
WASHER,PLAIN (Ref # 92022)	92022-239	2
PIN,10X37.5 (Ref # 92043)	92043-1217	2
SPRING,STEP,LH (Ref # 92081)	92081-1606	1
SPRING,STEP,RH (Ref # 92081A)	92081-1607	1
PIN,COTTER (Ref # 550)	550D2018	2