

PARTS DIAGRAM

ENGINE COVERS

Let the Good Times Roll®



1983 LTD Belt

PARTS LIST

ENGINE COVERS

ITEM NAME	PART NUMBER	QUANTITY
GASKET,TRANSMISSION C (Ref # 11009)	11060-1056	1
GASKET,CONTACT BREAKER (Ref # 11009A)	11009-1322	1
GASKET,GENERATOR COVE (Ref # 11009B)	11009-1328	1
GASKET,R.H ENGINE COV (Ref # 11009C)	14046-033	1
GASKET,KICK COVER (Ref # 11009D)	14046-034	1
CAP,CONTACT BREAKER (Ref # 11012)	11012-1267	1
BRACKET-A,MISSION COV (Ref # 11036)	11036-1678	1
COVER,MISSION (Ref # 14025)	14025-1554	1
COVER-CHAIN (Ref # 14026)	14026-1076	1
COVER-GENERATOR (Ref # 14031)	14031-1103	1
COVER-CLUTCH (Ref # 14032)	14032-1092	1
COVER,KICK (Ref # 14032A)	14032-112-2H	1
GAUGE,OIL LEVEL (Ref # 52005)	52005-1009	1
CLAMP,GENERATOR WIRE (Ref # 92037)	92037-1122	1
OIL SEAL,SC22325 (Ref # 92049)	92049-1048	1
SEAL-OIL (Ref # 92049A)	92049-1070	1
OIL SEAL,TB13225.5 (Ref # 92049B)	92051-005	1
BOLT,FLANGED,6X30 (Ref # 130)	130G0630	2
BOLT-FLANGED,6X95 (Ref # 130A)	130G0695	2
SCREW PAN HEAD 6X8 (Ref # 220)	220B0608	1
SCREW PAN HEAD 6X20 (Ref # 220A)	220B0620	5
SCREW PAN HEAD 6X30 (Ref # 220B)	220B0630	20
SCREW PAN HEAD 6X40 (Ref # 220C)	220B0640	7
SCREW PAN HEAD 6X60 (Ref # 220D)	220B0660	1
SCREW-PAN-WS-CROS (Ref # 223)	223B0512	2
WASHER PLAIN 6MM (Ref # 411)	411B0600	1