


1984 KZ750-K2 (Canada Only)

Kawasaki
Let the Good Times Roll®

PARTS DIAGRAM

STARTER MOTOR/STARTER CLUTCH

E1840-0045



1984 KZ750-K2 (Canada Only)

PARTS LIST

STARTER MOTOR/STARTER CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
GEAR,STARTER CLUTCH (Ref # 12046)	21170-003	1
CLUTCH ASSY,STARTER (Ref # 13193)	13193-1001	1
CARBON BRUSH (Ref # 21039)	21039-003	2
SPRING,CARBON BRUSH (Ref # 21040)	21040-003	2
SPROCKET,STARTER MOT (Ref # 21053)	21053-003	1
STARTER ELECTRIC (Ref # 21163)	21163-1020	1
WIRE,STARTER MOTOR LD (Ref # 26011)	26010-045	1
SWITCH ASSY,MAGNETIC (Ref # 27010)	21164-005	1
BOLT (Ref # 92001)	120P0816	3
SCREW,PAN HEAD,6X120 (Ref # 92009)	21099-005	2
NUT,LOCK 6MM (Ref # 92015)	92017-014	2
WASHER,THRUST,0.2T (Ref # 92022)	21025-011	3
SPACER,25X40X1 (Ref # 92026)	92026-1004	1
CIRCLIP (Ref # 92033)	92033-034	1
CLAMP,WIRING HARNESS (Ref # 92037)	21126-008	2
PIN (Ref # 92043)	92043-087	3
"O" RING,STARTING MTR (Ref # 92055)	21027-003	1
"O" RING,40M/M (Ref # 92055A)	21027-008	1
CHAIN,DYNAMO (Ref # 92057)	21070-010	1
GROMMET,CORD (Ref # 92071)	21017-017	2
DAMPER MAG SWITCH SHK (Ref # 92075)	21064-002	1
SPRING (Ref # 92081)	92081-110	3
ROLLER (Ref # 92122)	92122-004	3
BOLT-UPSET (Ref # 112)	112G0625	2
NUT 6MM (Ref # 312)	312B0600	2
WASHER SPRING 6MM (Ref # 461)	461F0600	4