


# 1984 GPz

## PARTS DIAGRAM

### INJECTORS/ELECTRICAL EQUIPMENT

E1530-0011



# 1984 GPz

## PARTS LIST

### INJECTORS/ELECTRICAL EQUIPMENT

| ITEM NAME                            | PART NUMBER | QUANTITY |
|--------------------------------------|-------------|----------|
| HOLDER,FUEL INJECTOR (Ref # 13091)   | 13091-1092  | 4        |
| PLATE,FUEL INJECTOR,B (Ref # 13169)  | 13169-1434  | 4        |
| CONTROL UNIT-ELECTRON (Ref # 21175)  | 21175-1007  | 1        |
| SENSOR-TEMPERATURE (Ref # 21176)     | 21176-1002  | 1        |
| SENSOR,AIR-TEMPERATUR (Ref # 21176A) | 21176-1003  | 1        |
| RELAY ASSY (Ref # 27002)             | 27002-1007  | 1        |
| ADAPTER,SENSOR (Ref # 41077)         | 41077-1004  | 1        |
| INJECTOR,FUEL (Ref # 49033)          | 49033-1001  | 4        |
| SCREW,TAPPING,3X12,BL (Ref # 92009)  | 92009-1028  | 2        |
| INSULATOR,FUEL INJECT (Ref # 92055)  | 92055-1082  | 4        |
| INSULATOR,FUEL INJECT (Ref # 92075)  | 92075-1240  | 4        |
| DAMPER,CONTROL UNIT (Ref # 92075A)   | 92075-1312  | 3        |
| BOLT-SOCKET (Ref # 120)              | 120S0540    | 8        |
| BOLT 6X12 (Ref # 180)                | 180B0612    | 2        |