

1997 SS

PARTS DIAGRAM

Ignition System

Let the Good Times Roll®

Exploded view diagram of a vehicle's rearview mirror assembly. The diagram shows the following components and their part numbers:

- 21130**: Mirror housing (top left)
- 92037**: Mirror housing (top left)
- 92190**: Mirror housing (top left)
- 11012**: Mirror housing (top left)
- 59071**: Mirror housing (top left)
- 670**: Mirror housing (top left)
- 11012B**: Mirror housing (top left)
- 92002C**: Mirror housing (top left)
- 92037A**: Mirror housing (top left)
- 311**: Mirror housing (top left)
- 410A**: Mirror housing (top left)
- 311**: Mirror housing (top left)
- 92071**: Mirror housing (top left)
- 92026**: Mirror housing (top left)
- 92070**: Mirror housing (top left)
- 26011**: Mirror housing (top left)
- 26011A**: Mirror housing (top left)
- 11012A**: Mirror housing (top left)
- 92002C**: Mirror housing (top left)
- 13091A**: Mirror housing (top left)
- 92002A**: Mirror housing (top left)
- 92002B**: Mirror housing (top left)
- 21066**: Mirror housing (top left)
- 14079**: Mirror housing (top left)
- 27010A**: Mirror housing (top left)
- 21121**: Mirror housing (top left)
- 156B**: Mirror housing (top left)
- 92072**: Mirror housing (top left)
- 11048**: Mirror housing (top left)
- 92002C**: Mirror housing (top left)
- 92002C**: Mirror housing (top left)
- 92002C**: Mirror housing (top left)
- 34001**: Mirror housing (top left)
- 156**: Mirror housing (top left)
- 156A**: Mirror housing (top left)
- 26004**: Mirror housing (top left)
- 27010**: Mirror housing (top left)
- 410**: Mirror housing (top left)
- 92022**: Mirror housing (top left)
- 21119**: Mirror housing (top left)
- 156A**: Mirror housing (top left)
- 59416**: Mirror housing (top left)
- 92055A**: Mirror housing (top left)
- 59416A**: Mirror housing (top left)
- 92055**: Mirror housing (top left)
- 92020**: Mirror housing (top left)
- 92002**: Mirror housing (top left)

The diagram also includes a "FRONT" arrow pointing to the left and a "Ref. Drive Shaft" label at the bottom left.

1997 SS

PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
BOLT-WP,6X14 (Ref # 156)	156R0614	1
BOLT-WP,6X22 (Ref # 156A)	156R0622	4
BOLT-WP (Ref # 156B)	156R0630	2
NUT-HEX,6MM (Ref # 311)	311R0600	4
CAP (Ref # 11012)	11012-3005	2
CAP,HOLDER (Ref # 11012A)	11012-3768	2
CAP (Ref # 11012B)	11012-3791	1
BRACKET,HIGH TENSION CORD (Ref # 11048)	11048-3736	1
HOLDER,HIGH TENSION CORD (Ref # 13091)	13091-3771	1
HOLDER,PLUG CAP (Ref # 13091A)	13091-3781	1
HOLDER-ASSY (Ref # 14079)	14079-3710	1
REGULATOR-VOLTAGE (Ref # 21066)	21066-3711	1
IGNITER (Ref # 21119)	21119-3734	1
COIL-IGNITION (Ref # 21121)	21121-3704	1
CAP-SPARK PLUG (Ref # 21130)	21130-3706	2
FUSE-ASSY (Ref # 26004)	26004-3712	1
WIRE-LEAD (Ref # 26011)	26011-3799	1
WIRE-LEAD (Ref # 26011A)	26011-3800	1
SWITCH,STARTER RELAY (Ref # 27010)	27010-3724	1
SWITCH (Ref # 27010A)	27010-3733	1
STAND,ELECTRIC CASE (Ref # 34001)	34001-3705	1
JOINT (Ref # 59071)	59071-3001	5
CASE-ELECTRIC,LWR (Ref # 59416)	59416-3728	1
CASE-ELECTRIC,UPP (Ref # 59416A)	59416-3742	1
BOLT,6X25 (Ref # 92002)	92002-3714	5
BOLT,6X35 (Ref # 92002A)	92002-3715	3
BOLT,6X16 (Ref # 92002B)	92002-3728	1
BOLT,6X12 (Ref # 92002C)	92002-3763	7
WASHER (Ref # 92022)	92022-3035	2

1997 SS

PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
SPACER (Ref # 92026)	92026-3703	2
CLAMP (Ref # 92037)	92037-1173	4
CLAMP (Ref # 92037A)	92037-3730	1
RING-O (Ref # 92055)	92055-1292	1
RING-O,ELECTRIC CASE (Ref # 92055A)	92055-3733	1
PLUG-SPARK,BR8ES(NGK) (Ref # 92070)	92070-2078	2
GROMMET (Ref # 92071)	92071-3004	2
GROMMET (Ref # 92071A)	92071-527	2
BAND (Ref # 92072)	92072-3778	2
TUBE,HIGH TENSION,L=330 (Ref # 92190)	92190-3707	1
TUBE,HIGH TENSION,L=210 (Ref # 92190A)	92190-3708	1
WASHER-PLAIN-SMALL,10MM (Ref # 410)	410B1000	2
WASHER-PLAIN-SMALL,6MM (Ref # 410A)	410S0600	2
O RING,16MM (Ref # 670)	670B2016	5