


1984 Tecate

PARTS DIAGRAM

REAR HUB/AXLE/CHAIN ('84 A1)

I 2240-0145



1984 Tecate

PARTS LIST

REAR HUB/AXLE/CHAIN ('84 A1)

ITEM NAME	PART NUMBER	QUANTITY
HOLDER,DISC PLATE (Ref # 13091)	13091-1358	1
HOUSING (Ref # 41046)	41046-4010-8T	1
AXLE,REAR HUB,L=866 (Ref # 41068)	41068-1174	1
AXLE,REAR HUB (Ref # 41068A)	41068-5001	1
AXLE,REAR HUB (Ref # 41068B)	41068-5001	1
FLANGE,REAR SPROCKET (Ref # 41086)	41086-1056	1
FLANGE,REAR SPROCKET (Ref # 41086A)	41086-1056	1
SPROCKET-HUB,42T (Ref # 42041)	42041-1130	1
RING (Ref # 43058)	43058-4002	1
RR-HUB (Ref # 49030)	49030-4013	2
BOLT,LUG (Ref # 92001)	92001-4006	8
NUT CASTLE,18MM (Ref # 92015)	42045-018	2
NUT,LOCK,32MM (Ref # 92015A)	92015-1493	2
WASHER,32.5X43X2.3 (Ref # 92022)	92022-1225	1
WASHER,18.3X34X4.5 (Ref # 92022A)	92022-1658	2
WASHER,18.3X34X4.5 (Ref # 92022B)	92022-1658	3
WASHER,12.5X28X4.5 (Ref # 92022C)	92022-4037	3
COLLAR (Ref # 92027)	92027-4025	1
SEAL-OIL,REAR HUB (Ref # 92049)	92049-4001	2
RING-O,33X1.6 (Ref # 92055)	92055-4002	2
DR CHAIN EK520SH-0 82 (Ref # 92057)	92057-4012	1
BOLT,HEX HEAD,10X16 (Ref # 113)	113G1016	6
BOLT-SMALL-FINE,12X30 (Ref # 113A)	113P1230	4
WASHER SPRING 12MM (Ref # 461)	461F1200	4
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	2
BEARING-BALL,#6007 (Ref # 601)	601A6007	2