


1991 SC

PARTS DIAGRAM

Electrical Equipment

Kawasaki
Let the Good Times Roll®

F3181



1991 SC

PARTS LIST

Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
HOLDER (Ref # 13091)	13091-3762	3
WIRE-LEAD,BATTERY-RELAY (Ref # 26011)	26011-3783	1
WIRE-LEAD,STARTER-RELAY (Ref # 26011A)	26011-3784	1
WIRE-LEAD,BATTERY-STARTER (Ref # 26011B)	26011-3793	1
BATTERY,YB16CL-B,12V 19AH (Ref # 26012)	26012-3716	1
BAND,L=123 (Ref # 92072)	92072-030	1
BAND (Ref # 92072A)	92072-3778	2