

1990 550 SX


PARTS DIAGRAM

Starter Motor

Kawasaki

Let the Good Times Roll®

E1840



1990 550 SX

PARTS LIST

Starter Motor

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
COVER,RR (Ref # 14024)	14025-3027	1
COVER,FR (Ref # 14024A)	14025-3028	1
HOLDER-ASSY,BRUSH (Ref # 14079)	14079-3002	1
BRUSH,(+) (Ref # 21039)	21039-3003	2
BRUSH,(-) (Ref # 21039A)	21039-3004	1
ARMATURE (Ref # 21080)	21080-3701	1
STARTER-ELECTRIC (Ref # 21163)	21163-3003-YR	1
YOKE (Ref # 49117)	49117-3002	1
GEAR-SPUR (Ref # 59051)	59051-3005	1
BOLT,8X70 (Ref # 92002)	92002-3719	2
BOLT,6X20 (Ref # 92002A)	92002-3755	2
SCREW,6X107 (Ref # 92009)	92011-549	2
SCREW,4X8 (Ref # 92009A)	92011-550	2
WASHER,SET (Ref # 92022)	92022-3044	1
SHIM,STARTER,T=0.4 (Ref # 92025)	92025-3012	AR
SHIM,STARTER,T=0.6 (Ref # 92025A)	92025-3013	AR
SHIM,STARTER,T=0.8 (Ref # 92025B)	92025-3014	AR
COLLAR,STOPPER,PINION (Ref # 92027)	92027-513	1
RING-SNAP (Ref # 92033)	92036-517	1
RING-O (Ref # 92055)	92055-516	1
RING-O (Ref # 92055A)	92055-517	2
SPRING,BRUSH (Ref # 92081)	92081-540	3
SPRING,RETURN (Ref # 92081A)	92081-541	1
WASHER-PLAIN-SMALL,8MM (Ref # 410)	410S0800	2
O RING,5MM (Ref # 670)	670B1505	2
O RING,6MM (Ref # 670A)	670B1506	2