


1979 KV75-A8

PARTS DIAGRAM

HANDLEBAR ('76-'80)

Kawasaki

Let the Good Times Roll®



1979 KV75-A8

PARTS LIST

HANDLEBAR ('76-'80)

ITEM NAME	PART NUMBER	QUANTITY
HANDLEBAR,RH (Ref # 1)	46007-010	1
HOLDER-HANDLEBAR (Ref # 2)	46012-009	2
SPRING (Ref # 3)	92081-090	2
KNOB-HANDLEBAR HOLDER (Ref # 4)	46129-001	2
BOLT,HEX HEAD,10X18 (Ref # 5)	113G1018	4
WASHER SPRING 10MM (Ref # 6)	461F1000	4
HANDLEBAR,LH (Ref # 7)	46007-011	1
GRIP ASSY,R.H (Ref # 8)	46017-077	1
GRIP ASSY,R.H (Ref # 8)	46017-1009	1
GRIP ASSY,THROTTLE (Ref # 9)	46019-024	1
GRIP ASSY,THROTTLE (Ref # 9)	46019-041	1
RUBBER,R.H.GRIP (Ref # 10)	46061-015	1
SCREW PAN HEAD 5X20 (Ref # 11)	220B0520	4
SCREW PAN HEAD 5X18 (Ref # 12)	220B0518	2
KNOB ASSY R.H SWITCH (Ref # 13)	46043-002	1
CASE R.H SWITCH LOWER (Ref # 14)	46022-012	1
CASE,R.H LOWER (Ref # 14)	46022-017	1
GRIP-ASSY,RH (Ref # 15)	46017-1071	1
CASE,R.H. UPPER (Ref # 15)	46040-015	1
NUT-LOCK,5MM (Ref # 16)	92019-014	2
LEVER FRONT BRAKE (Ref # 17)	46058-004	1
BOLT,HEX HEAD,5X22 (Ref # 18)	92007-046	2
NUT LOCK ADJUST SCREW (Ref # 19)	46056-001	2
SCREW CABLE ADJUST (Ref # 20)	46055-003	2
LEVER-CLUTCH (Ref # 21)	46092-015	1
SWITCH ASSY LH BUTTON (Ref # 22)	46078-003	1
KNOB ASSY L.H SWITCH (Ref # 23)	46088-001	1
CASE L.H SWITCH UPPER (Ref # 24)	46086-007	1
CASE,L.H UPPER (Ref # 24)	46086-025	1

1979 KV75-A8

PARTS LIST

HANDLEBAR ('76-'80)

ITEM NAME	PART NUMBER	QUANTITY
CASE L.H SWITCH LOWER (Ref # 25)	46077-008	1
CASE, L.H. LOWER (Ref # 25)	46077-026	1
46074-092 (Canada) (Ref # 26)	46074-067	1
GRIP ASSY,L.H (Ref # 26)	46074-092	1
GRIP ASSY,L.H. (Ref # 26)	46074-1005	1
RUBBER,L.H GRIP (Ref # 27)	46075-020	1
RUBBER,L.H GRIP (Ref # 27)	46075-028	1
DUST COVER (Ref # 28)	49016-1028	1