


1979 KX80

PARTS DIAGRAM

IGNITION

Kawasaki

Let the Good Times Roll®



1979 KX80

PARTS LIST

IGNITION

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET,6X20 (Ref # 1)	112G0620	2
WASHER SPRING 6MM (Ref # 2)	461F0600	2
STATOR ASSY,MAGNETO (Ref # 3)	21003-1018	1
FLYWHEEL,MAGNETO (Ref # 4)	21050-1010	1
IGNITER (Ref # 5)	21119-1007	1
SCREW-PAN-CROS (Ref # 6)	220B0514	3
WASHER PLAIN 5MM (Ref # 7)	410B0500	3
WASHER PLAIN (Ref # 8)	92022-024	2
BAND,SHORT (Ref # 9)	92072-030	1
COIL,IGNITION (Ref # 10)	21121-1020	1
CAP SPARK PLUG (Ref # 11)	21130-009	1
SPRING-SPARK PLUG CAP (Ref # 12)	92101-001	1
NUT (Ref # 13)	92019-008	2
SPARK PLUG B8HS (Ref # 14)	B8HS	1
SPARK PLUG B8ES (Ref # 14)	B8ES	1
CAP,SPARK PLUG (Ref # 15)	21160-005	1
BOLT,FLANGED,6X12 (Ref # 16)	130G0612	1
IGNITER (Ref # 17)	21119-1016	1
FLYWHEEL,MAGNETO (Ref # 18)	21007-1018	1
STATOR (Ref # 19)	21003-1239	1
COIL,IGNITION (Ref # 20)	21121-1060	1
CAP,SPARK PLUG (Ref # 21)	21130-1006	1
CLAMP,SPARK PLUG CAP (Ref # 22)	92037-1173	1
SCREW-PAN-CROS (Ref # 23)	220B0310	1
TERMINAL,PLUG CAP (Ref # 24)	21169-001	1
NUT 6MM (Ref # 25)	311B0600	2