


1980 KX80

PARTS DIAGRAM

IGNITION

Kawasaki

Let the Good Times Roll®



1980 KX80

PARTS LIST

IGNITION

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET,6X20 (Ref # 1)	112G0620	
WASHER SPRING 6MM (Ref # 2)	461F0600	
STATOR ASSY,MAGNETO (Ref # 3)	21003-1018	
FLYWHEEL,MAGNETO (Ref # 4)	21050-1010	
IGNITER (Ref # 5)	21119-1007	
SCREW-PAN-CROS (Ref # 6)	220B0514	
WASHER PLAIN 5MM (Ref # 7)	410B0500	
WASHER PLAIN (Ref # 8)	92022-024	
BAND,SHORT (Ref # 9)	92072-030	
COIL,IGNITION (Ref # 10)	21121-1020	
CAP SPARK PLUG (Ref # 11)	21130-009	
SPRING-SPARK PLUG CAP (Ref # 12)	92101-001	
NUT (Ref # 13)	92019-008	
SPARK PLUG B8HS (Ref # 14)	B8HS	
SPARK PLUG B8ES (Ref # 14)	B8ES	
CAP,SPARK PLUG (Ref # 15)	21160-005	
BOLT,FLANGED,6X12 (Ref # 16)	130G0612	
IGNITER (Ref # 17)	21119-1016	
FLYWHEEL,MAGNETO (Ref # 18)	21007-1018	
STATOR (Ref # 19)	21003-1239	
COIL,IGNITION (Ref # 20)	21121-1060	
CAP,SPARK PLUG (Ref # 21)	21130-1006	
CLAMP,SPARK PLUG CAP (Ref # 22)	92037-1173	
SCREW-PAN-CROS (Ref # 23)	220B0310	
TERMINAL,PLUG CAP (Ref # 24)	21169-001	
NUT 6MM (Ref # 25)	311B0600	