


1974 G3SS-D

PARTS DIAGRAM

IGNITION ('69-'73)

Kawasaki

Let the Good Times Roll®



1974 G3SS-D

PARTS LIST

IGNITION ('69-'73)

ITEM NAME	PART NUMBER	QUANTITY
COIL IGNITION (Ref # 1)	21121-1048	1
CAP-SPARK PLUG (Ref # 2)	21130-016	1
GROMMET-PLUG CAP,A (Ref # 3)	21131-004	1
GROMMET,SPARK PLG CAP (Ref # 4)	21132-005	1
RECTIFIER (Ref # 5)	21061-5001	1
GROMMET WIRING HARN (Ref # 6)	21017-002	1
MAGNETO FLYWEEL (Ref # 7~21)	21002-008	1
MAGNETO FLYWHEEL (Ref # 7~21)	21002-018	1
COIL LIGHTING A (Ref # 7)	21047-006	1
COIL LIGHTING A (Ref # 7)	21047-010	1
COIL LIGHTING B (Ref # 8)	21047-007	1
COIL LIGHTING B (Ref # 8)	21047-011	1
COIL PRIMARY (Ref # 9)	21049-006	1
PLATE-COIL,MAGNETO (Ref # 10)	21048-1002	1
MAGNETO ASSY (Ref # 11)	21002-1055	1
CONDENSER (Ref # 12)	21013-006	1
BREAKER ASSY CONTACT (Ref # 13)	21008-006	1
FELT OIL (Ref # 14)	21019-005	1
WIRING HARNESS MAGNT (Ref # 15)	21029-003	1
WIRING HARNESS MAG (Ref # 15)	21029-014	1
SCREW PAN HEAD 4X30 (Ref # 16)	220E0430	6
SCREW PAN HEAD 4X6 (Ref # 17)	220B0406	3
SCREW-PAN-CRSOSS,4X12 (Ref # 18)	220B0412	1
WASHER PLAIN 4MM (Ref # 19)	410B0400	1
WASHER-SPRING, 4 M/M (Ref # 20)	461F0400	9
CLAMP WIRING HARNESS (Ref # 21)	21037-002	1
SCREW CNTSNK HD 6X14 (Ref # A22)	221B0614	2