


1970 G3SS

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT (EXCEPT G3S)

Kawasaki

Let the Good Times Roll®



1970 G3SS

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT (EXCEPT G3S

ITEM NAME	PART NUMBER	QUANTITY
WIRING HARNESS MAIN (Ref # 1)	26001-018	1
WIRING HARNESS-MAIN (Ref # 2)	26001-050	1
WIRING HARNESS REAR (Ref # 3)	26002-007	1
FUSE ASSY (Ref # 4)	26004-026	1
FUES ASSY (Ref # 5)	26004-008	AL
FUSE 10A (Ref # 6)	26006-001	1
FUSE 10A (Ref # 7)	26006-003	1
SWITCH-BRAKE LAMP (Ref # 8)	27010-018	1
SPRING BRAKE LAMP SW (Ref # 9)	27012-005	1
SPRING BRAKE LAMP SW (Ref # 10)	27011-006	1
SWITCH-ASSY-IGNITION (Ref # 11)	27005-1059	1
SWITCH ASSY,IGNITION (Ref # 12)	27005-1016	1
KEY SET NO.301 (Ref # 13)	27008-024-01	1
KEY SET NO.302 (Ref # 13)	27008-024-02	1
KEY SET NO.303 (Ref # 13)	27008-024-03	1
KEY SET NO.304 (Ref # 13)	27008-024-04	1
KEY SET NO.305 (Ref # 13)	27008-024-05	1
KEY SET NO.235 (Ref # 14)	27008-034-35	1
KEY SET NO.236 (Ref # 14)	27008-034-36	1
KEY SET NO.237 (Ref # 14)	27008-034-37	1
KEY SET NO.238 (Ref # 14)	27008-034-38	1
KEY SET NO.239 (Ref # 14)	27008-034-39	1
KEY SET NO.321 (Ref # 14)	27008-034-21	1
KEY SET NO.322 (Ref # 14)	27008-034-22	1
KEY SET NO.323 (Ref # 14)	27008-034-23	1
KEY SET NO.324 (Ref # 14)	27008-034-24	1
SCREW PAN HEAD 5X8 (Ref # 15)	220B0508	2
WASHER SPRING 5MM (Ref # 16)	461F0500	2
BAND RUBBER (Ref # 17)	92072-018	4

1970 G3SS

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT (EXCEPT G3S



ITEM NAME	PART NUMBER	QUANTITY
BAND RUBBER (Ref # 18)	92072-013	2
YUA BAT 6N4-2A-3 (Ref # 19)	K26012-006	1
YUA BAT 6N4-2A-5 (Ref # 20)	K26012-020	1
LEAD WIRE (Ref # 21)	26011-042	1