

# 1974 G3SS-D



## PARTS DIAGRAM

## CHASSIS ELECTRICAL EQUIPMENT (G3SS-C) ('

# Kawasaki

**Let the Good Times Roll®**

Re



# 1974 G3SS-D

## PARTS LIST

### CHASSIS ELECTRICAL EQUIPMENT (G3SS-C) ('

| ITEM NAME                        | PART NUMBER  | QUANTITY |
|----------------------------------|--------------|----------|
| WIRING HARNESS-MAIN (Ref # 1)    | 26001-079    | 1        |
| WIRING HARNESS REAR (Ref # 2)    | 26002-007    | 1        |
| LEAD WIRE (Ref # 3)              | 26011-042    | 1        |
| WIRE-LEAD (Ref # 4)              | 26011-058    | 1        |
| FUES ASSY (Ref # 5,6)            | 26004-008    | 1        |
| FUSE 10A (Ref # 6)               | 26006-003    | 2        |
| SWITCH ASSY,IGNITION (Ref # 7,8) | 27005-1016   | 1        |
| KEY SET NO.321 (Ref # 8)         | 27008-034-21 | 1        |
| KEY SET NO.322 (Ref # 8)         | 27008-034-22 | 1        |
| KEY SET NO.323 (Ref # 8)         | 27008-034-23 | 1        |
| KEY SET NO.324 (Ref # 8)         | 27008-034-24 | 1        |
| KEY SET NO.235 (Ref # 8)         | 27008-034-35 | 1        |
| KEY SET NO.236 (Ref # 8)         | 27008-034-36 | 1        |
| KEY SET NO.237 (Ref # 8)         | 27008-034-37 | 1        |
| KEY SET NO.238 (Ref # 8)         | 27008-034-38 | 1        |
| KEY SET NO.239 (Ref # 8)         | 27008-034-39 | 1        |
| SCREW PAN HEAD 5X12 (Ref # 9)    | 220B0512     | 2        |
| WASHER SPRING 5MM (Ref # 10)     | 461F0500     | 2        |
| SWITCH-BRAKE LAMP (Ref # 11)     | 27010-018    | 1        |
| SPRING BRAKE LAMP SW (Ref # 12)  | 27011-006    | 1        |
| SPRING BRAKE LAMP SW (Ref # 13)  | 27012-005    | 1        |
| YUA BAT 6N4-2A-5 (Ref # 14)      | K26012-020   | 1        |
| BAND,MIDDLE (Ref # 15)           | 92072-031    | 3        |
| BAND,LONG (Ref # 16)             | 92072-032    | 3        |
| LAMP ASY-FR TURN SIG (Ref # 17)  | 23037-005    | 2        |
| SCREW-PAN HEAD,4X20 (Ref # 18)   | 220E0420A    | 8        |
| WASHER-PLAIN,4MM (Ref # 19)      | 23058-002    | 8        |
| LENS,TURN SIGNAL LAMP (Ref # 20) | 23048-1001   | 4        |
| GASKET-SIG LAMP LENS (Ref # 21)  | 23050-003    | 4        |

# 1974 G3SS-D

## PARTS LIST

### CHASSIS ELECTRICAL EQUIPMENT (G3SS-C) ('

| ITEM NAME                        | PART NUMBER | QUANTITY |
|----------------------------------|-------------|----------|
| BULB,6V 21CP (Ref # 22)          | 92069-056   | 4        |
| BRACKET,SIGNAL LAMP (Ref # 23)   | 23051-1013  | 2        |
| BRACKET,FRNT TURN SIG (Ref # 24) | 23051-1004  | 2        |
| DAMPER RUBBER (Ref # 25)         | 23066-003   | 2        |
| WIRE-TURN SIGNAL LEAD (Ref # 26) | 26011-061   | 2        |
| COVER-WIRING HARNESS (Ref # 27)  | 26009-004   | 2        |
| SCREW PAN HEAD 3X5 (Ref # 28)    | 220B0305A   | 2        |
| BOLT-UPSET (Ref # 29)            | 112G0630    | 4        |
| WASHER PLAIN 6MM (Ref # 30)      | 410B0600    | 8        |
| WASHER SPRING 6MM (Ref # 31)     | 461F0600    | 4        |
| NUT 6MM (Ref # 32)               | 311B0600    | 4        |
| BOLT (Ref # 33)                  | 110N0516    | 4        |
| WASHER SPRING 5MM (Ref # 34)     | 461F0500    | 2        |
| WASHER-PLAIN,5MM (Ref # 35)      | 410D0500    | 4        |
| LAMP-REAR TURN SIGNAL (Ref # 36) | 23040-033   | 2        |
| BRACKET-TURN SIG LAMP (Ref # 37) | 23051-041   | 2        |
| DAMPER RUBBER (Ref # 38)         | 92075-148   | 4        |
| COLLAR 12.7X17.3X30 (Ref # 39)   | 92027-168   | 2        |
| SPRING (Ref # 40)                | 92081-111   | 2        |
| WASHER CUP 12.5X35X4T (Ref # 41) | 92022-235   | 2        |
| CLAMP-RR SIGNAL LAMP (Ref # 42)  | 92037-087   | 2        |
| WASHER SPRING 12MM (Ref # 43)    | 461F1200    | 2        |
| NUT-HEX-FINE,12MM (Ref # 44)     | 315B1200    | 2        |
| KEY,BLANK (Ref # 45)             | 27008-1016  | 1        |
| KEY,BLANK (Ref # 45)             | 27008-1017  | 1        |
| KEY,BLANK (Ref # 45)             | 27008-1018  | 1        |
| KEY,BLANK (Ref # 45)             | 27008-1019  | 1        |