


# 1970 G3SS

## PARTS DIAGRAM

### CHASSIS ELECTRICAL EQUIPMENT ('74-'75)

**Kawasaki**  
Let the Good Times Roll®



# 1970 G3SS

## PARTS LIST

### CHASSIS ELECTRICAL EQUIPMENT ('74-'75)

| ITEM NAME                                  | PART NUMBER  | QUANTITY |
|--------------------------------------------|--------------|----------|
| WIRING HARNESS,MAIN (Ref # 1)              | 26001-114    | 1        |
| WIRING HARNESS,MAIN (Ref # 1)              | 26001-126    | 1        |
| WIRING HARNESS-REAR (Ref # 2)              | 26002-030    | 1        |
| WIRE,RECTIFIER LEAD (Ref # 3)              | 26011-072    | 1        |
| FUES ASSY (Ref # 4)                        | 26004-008    | 1        |
| FUSE 10A (Ref # 5)                         | 26006-003    | 1        |
| SWITCH ASSY,IGNITION (Ref # 6)             | 27005-1016   | 1        |
| KEY SET NO.321 (Ref # 7)                   | 27008-034-21 | 1        |
| KEY SET NO.322 (Ref # 7)                   | 27008-034-22 | 1        |
| KEY SET NO.323 (Ref # 7)                   | 27008-034-23 | 1        |
| KEY SET NO.324 (Ref # 7)                   | 27008-034-24 | 1        |
| KEY SET NO.235 (Ref # 7)                   | 27008-034-35 | 1        |
| KEY SET NO.236 (Ref # 7)                   | 27008-034-36 | 1        |
| KEY SET NO.237 (Ref # 7)                   | 27008-034-37 | 1        |
| KEY SET NO.238 (Ref # 7)                   | 27008-034-38 | 1        |
| KEY SET NO.239 (Ref # 7)                   | 27008-034-39 | 1        |
| KEY SET NO.140 (Ref # 7)                   | 27008-034-40 | 1        |
| KEY SET NO.141 (Ref # 7)                   | 27008-034-41 | 1        |
| KEY SET NO.142 (Ref # 7)                   | 27008-034-42 | 1        |
| KEY SET NO.143 (Ref # 7)                   | 27008-034-43 | 1        |
| SCREW PAN HEAD 5X12 (Ref # 8)              | 220B0512     | 2        |
| WASHER SPRING 5MM (Ref # 9)                | 461F0500     | 2        |
| SWITCH-BRAKE LAMP (Ref # 10)               | 27010-018    | 1        |
| SWITCH-BRAKE LAMP (Ref # 10)               | 27010-018    | 1        |
| SPRING BRAKE LAMP SW (Ref # 11)            | 27011-006    | 1        |
| HOOK, BRAKE L;AMP SWITCH SPRING (Ref # 12) | 27012-005    | 1        |
| RELAY-TURN SIGNAL (Ref # 13)               | 27002-013    | 1        |
| YUA BAT 6N4-2A-5 (Ref # 14)                | K26012-020   | 1        |
| BAND RUBBER (Ref # 15)                     | 92072-018    | 1        |

# 1970 G3SS

## PARTS LIST

### CHASSIS ELECTRICAL EQUIPMENT ('74-'75)



| ITEM NAME              | PART NUMBER | QUANTITY |
|------------------------|-------------|----------|
| BAND,MIDDLE (Ref # 16) | 92072-031   | 3        |
| BAND,LONG (Ref # 17)   | 92072-032   | 2        |
| WIRE-LEAD (Ref # 18)   | 26011-032   | 2        |
| WIRE-LEAD (Ref # 19)   | 26011-032   | 1        |
| KEY,BLANK (Ref # 20)   | 27008-1016  | 1        |
| KEY,BLANK (Ref # 20)   | 27008-1017  | 1        |
| KEY,BLANK (Ref # 20)   | 27008-1018  | 1        |
| KEY,BLANK (Ref # 20)   | 27008-1019  | 1        |