


# 1973 G4TR-C

## PARTS DIAGRAM

### HANDLEBAR G4TR-B 1/2 ('70-'73)

**Kawasaki**  
Let the Good Times Roll®



**G4TR**

# 1973 G4TR-C

## PARTS LIST

### HANDLEBAR G4TR-B 1/2 ('70-'73)

| ITEM NAME                        | PART NUMBER  | QUANTITY |
|----------------------------------|--------------|----------|
| HANDLEBAR (Ref # 1)              | 46004-004    |          |
| DUST COVER (Ref # 2)             | 46071-002    |          |
| BOLT HEX HEAD 5X20 (Ref # 3)     | 92007-020    |          |
| COLLAR LEVER (Ref # 4)           | 46059-011    |          |
| HOLDER-FR BRK LEV,BLK (Ref # 5)  | 46060-009-21 |          |
| LEVER FRONT BRAKE (Ref # 6)      | 46058-004    |          |
| WASHER LOCK 5MM (Ref # 7)        | 464H0500     |          |
| NUT 5MM (Ref # 8)                | 312B0500     |          |
| BOLT HEX HEAD 6X25 (Ref # 9)     | 110N0625     |          |
| WASHER PLAIN 6MM (Ref # 10)      | 410B0600     |          |
| SCREW,CABLE ADJUST (Ref # 11)    | 46055-009    |          |
| NUT-LOCK (Ref # 12)              | 46056-005    |          |
| SWITCH-FR. BRAKE LAMP (Ref # 13) | 27021-004    |          |
| HOLDER-CLUTCH LEV,BLK (Ref # 14) | 46094-011-21 |          |
| HOLDER-CLUTCH LEV,BLK (Ref # 14) | 46094-011-21 |          |
| LEVER-CLUTCH (Ref # 15)          | 46092-015    |          |
| KNOB-L.H SWITCH (Ref # 16)       | 46044-011    |          |
| SCREW CNTSNK HD 3X8 (Ref # 17)   | 221B0308A    |          |
| SPRING L.H SW KNOB (Ref # 18)    | 46031-003    |          |
| CASE L.H SWITCH UPPER (Ref # 19) | 46086-013    |          |
| HOLDER L.H SW UPPER A (Ref # 20) | 46085-013    |          |
| SCREW PAN HEAD 3X5 (Ref # 21)    | 220B0305A    |          |
| PLATE L.H SW CONTACT (Ref # 22)  | 46080-002    |          |
| SWITCH L.H (Ref # 23)            | 46089-003    |          |
| SPRING L.H SWITCH (Ref # 24)     | 46031-004    |          |
| CONTACT L.H SWITCH (Ref # 25)    | 46079-002    |          |
| HOLDER L.H SW LOWER B (Ref # 26) | 46085-014    |          |
| SCREW PAN HEAD 3X8 (Ref # 27)    | 220B0308     |          |
| KNOB-SWITCH (Ref # 28)           | 46044-006    |          |

# 1973 G4TR-C

## PARTS LIST

### HANDLEBAR G4TR-B 1/2 ('70-'73)

| ITEM NAME                        | PART NUMBER  | QUANTITY |
|----------------------------------|--------------|----------|
| WASHER (Ref # 29)                | 92095-010    |          |
| HOLDER L.H SW LOWER (Ref # 30)   | 46085-015    |          |
| WIRING HARNESS-L.H SW (Ref # 31) | 46082-017    |          |
| SWITCH ASSY,HORN BUTN (Ref # 32) | 27010-1009   |          |
| SWITCH ASSY,HORN BUTN (Ref # 33) | 27010-1009   |          |
| SWITCH ASSY,HORN BUTN (Ref # 34) | 27010-1009   |          |
| SLIDE BLOCK AY-L.H SW (Ref # 35) | 46089-004    |          |
| CASE L.H SWITCH LOWER (Ref # 36) | 46077-015    |          |
| SCREW-PAN-CROS,5X25 (Ref # 37)   | 220B0525     |          |
| RUBBER-L.H.GRIP (Ref # 38)       | 46075-018    |          |
| CASE-RH LOWER (Ref # 39)         | 46023-008    |          |
| CASE-RH UPPER (Ref # 40)         | 46041-008    |          |
| GRIP ASSY-THROTTLE (Ref # 41)    | 46019-020    |          |
| RUBBER-R.H. GRIP (Ref # 42)      | 46061-013    |          |
| SWITCH-ENGINE STOP (Ref # 43)    | 46027-008    |          |
| WIRING HARNESS-STP SW (Ref # 44) | 46082-021    |          |
| GROMMET-WIRING HARNES (Ref # 45) | 92071-060    |          |
| SCREW PAN HEAD 3X5 (Ref # 46)    | 220B0305A    |          |
| LEVER ASSY,STARTER (Ref # 47)    | 46109-012    |          |
| LEVER ASSY,STARTER (Ref # 47)    | 46109-012    |          |
| LEVER-CHANGE (Ref # 48)          | 46131-002    |          |
| REAR VIEW MIRROR,L.H (Ref # 49)  | 56003-009    |          |
| REAR VIEW MIRROR,R.H (Ref # 50)  | 56002-020    |          |
| CASE ASSY-L.H (Ref # 51)         | 46091-004    |          |
| CASE ASSY,R.H,BLACK (Ref # 52)   | 46018-020-10 |          |
| SWITCH ASSY,HORN BUTN (Ref # 53) | 27010-1009   |          |