



1971 G4TR-A

PARTS DIAGRAM

METER/IGNITION SWITCH G4TR/A/B ('70-'73)

Kawasaki
Let the Good Times Roll®



G4TR/A

1971 G4TR-A

PARTS LIST

METER/IGNITION SWITCH G4TR/A/B ('70-'73)

ITEM NAME	PART NUMBER	QUANTITY
SPEEDOMETER ASSY MPH (Ref # 1)	25005-039	
BULB 6V 1.5W (Ref # 2)	92069-024	
BULB-6V 3W (Ref # 3)	92069-053	
SOCKET SPEEDOMETER (Ref # 4)	25011-013	
COVER-SPEEDOMETER (Ref # 5)	25012-005	
CLAMP CABLE (Ref # 6)	25022-002	
DAMPER RUBB SPEEDMETR (Ref # 7)	92075-024	
WASHER 6.5X20X1.6T (Ref # 8)	92022-125	
WASHER SPRING 6MM (Ref # 9)	461F0600	
NUT 6MM (Ref # 10)	311B0600	
KEY SET NO.235 (Ref # 11)	27008-034-35	
KEY SET NO.239 (Ref # 11)	27008-034-39	
KEY SET NO.321 (Ref # 11)	27008-034-21	
KEY SET NO.324 (Ref # 11)	27008-034-24	
KEY,BLANK (Ref # 11)	27008-1016	
KEY,BLANK (Ref # 11)	27008-1017	
KEY,BLANK (Ref # 11)	27008-1018	
KEY,BLANK (Ref # 11)	27008-1019	
HOUSING IGNITION SW (Ref # 12)	27009-007	
SCREW PAN HEAD 5X12 (Ref # 13)	220B0512	
WASHER SPRING 5MM (Ref # 14)	461F0500	
SCREW PAN HEAD 6X12 (Ref # 15)	220E0612	
WASHER SPRING 6MM (Ref # 16)	461F0600	
SWITCH ASSY,IGNITION (Ref # 17)	27005-1016	
SWITCH ASSY,IGNITION (Ref # 17)	27005-1016	