


1972 G5

PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL ('72-'73 G5-

Kawasaki
Let the Good Times Roll®



1972 G5

PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL ('72-'73 G5-

ITEM NAME	PART NUMBER	QUANTITY
STEP-ASSY,FR,LH (Ref # 1)	34027-1114	1
WASHER PL 22.5X36X2.3 (Ref # 2)	92022-204	2
PIN-FOOTREST BAR FIT (Ref # 3)	92043-080	2
HOLDER-FOTREST BAR,LH (Ref # 4)	34003-030	1
STEP-ASSY,FR,RH (Ref # 5)	34027-1115	1
HOLDER-FOTREST BAR,RH (Ref # 6)	34003-031	1
BOLT HEX HEAD 8X14 (Ref # 7)	110G0814	4
WASHER SPRING 8MM (Ref # 8)	461F0800	6
BOLT-SMALL-UPSET,8X16 (Ref # 9)	115G0816	2
WASHER PLAIN 8MM (Ref # 10)	410B0800	2
PIN COTTER 2.5X16 (Ref # 11)	550D2516	2
STAND-SIDE (Ref # 12)	34024-037	1
STAND-SIDE (Ref # 12)	34024-037	1
SPRING MAIN STAND (Ref # 13)	34023-005	1
BOLT,10X28 (Ref # 14)	113G1028	1
NUT 10MM (Ref # 15)	315B1000	1
PEDAL-BRAKE,BLACK (Ref # 16)	43001-042-10	1
SPRING-BRAKE PEDAL (Ref # 17)	43005-020	1
WASHER BRAKE PEDAL (Ref # 18)	92022-085	1
PIN COTTER 3.0X30 (Ref # 19)	550D3030	1
BRAKE ROD ASSY (Ref # 20~23)	43010-5001	1
ROD ASSY-BRAKE (Ref # 20~23)	43010-012	1
SPRING,BRAKE ROD (Ref # 21)	43012-001	1
PIN BRAKE (Ref # 22)	92043-039	1
NUT-BRAKE ROD ADJUST (Ref # 23)	92015-042	1
WASHER PLAIN 5MM (Ref # 24)	410B0500	1
PIN COTTER 2.0X15 (Ref # 25)	550D2015	1
PIN-BRAKE CABLE FIT (Ref # 26)	92043-092	1
WASHER PLAIN 6MM (Ref # 27)	410B0600	1