


1977 KH100-B8

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT

Kawasaki
Let the Good Times Roll®



1977 KH100-B8

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT

ITEM NAME	PART NUMBER	QUANTITY
WIRING HARNESS,MAIN (Ref # 1)	26001-133	
WIRING HARNESS-REAR (Ref # 2)	26002-030	
WIRE, RECTIFIER LEAD (Ref # 3)	26011-072	
FUSE ASSY (Ref # 4)	26004-025	
FUSE 15A (Ref # 5)	26006-007	
SWITCH,IGNITION (Ref # 6)	27005-084	
KEY SET NO.321 (Ref # 7)	27008-034-21	
KEY SET NO.143 (Ref # 7)	27008-034-43	
SCREW PAN HEAD 6X12 (Ref # 8)	220B0612	
WASHER SPRING 6MM (Ref # 9)	461F0600	
SWITCH-BRAKE LAMP (Ref # 10)	27010-015	
SPRING BRAKE LAMP SW (Ref # 11)	27011-006	
SPRING BRAKE LAMP SW (Ref # 12)	27012-005	
HORN (Ref # 13)	27003-072	
BOLT-UPSET,6X12 (Ref # 14)	112G0612	
WASHER PLAIN 6MM (Ref # 15)	411B0600	
RELAY-TURN SIGNAL (Ref # 16)	27002-015	
WASHER 6.5X20X1.6T (Ref # 17)	92022-125	
SCREW PAN HEAD 6X16 (Ref # 18)	220B0616	
BAND,SHORT (Ref # 19)	92072-030	
BAND,LONG (Ref # 20)	92072-032	
BAND,WIRING HARNESS (Ref # 21)	92072-056	
HOLDER-SPARE FUSE (Ref # 22)	26016-004	
FUSE 15A (Ref # 23)	26006-007	
YUA BAT 6N4-2A-5 (Ref # 24)	K26012-020	
YUA BAT 6N4-2A-5 (Ref # 24)	K26012-020	
LABEL-WARNING,BATTERY (Ref # 25)	56040-1036	
SWITCH ASSY,IGNITION (Ref # 26)	27005-085	
KEY,BLANK (Ref # 27)	27008-1016	

1977 KH100-B8

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT



ITEM NAME	PART NUMBER	QUANTITY
KEY,BLANK (Ref # 27)	27008-1017	
KEY,BLANK (Ref # 27)	27008-1018	
KEY,BLANK (Ref # 27)	27008-1019	